Dell Tower Plus EBT2250

Owner's Manual



Notes, cautions, and warnings

(i) NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2024-2025 Dell Inc. or its subsidiaries. All rights reserved. Dell Technologies, Dell, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

Chapter 1: Views of Dell Tower EBT2250	6
Front	
Back	8
Back Panel	9
Chapter 2: Set up your computer	11
Chapter 3: Specifications of Dell Tower EBT2250	15
Dimensions and weight	
Processor	
Chipset	
Operating system	
Memory	
Ports and connectors	
Ethernet	
Wireless module	
Storage	
GPU—Integrated	
Video	21
Audio	21
Media-card reader	22
Power ratings	22
Power supply connector	23
Operating and storage environment	23
Chapter 4: Working inside your computer	24
Safety instructions	24
Before working inside your computer	24
Safety precautions	25
Electrostatic discharge—ESD protection	25
ESD Field Service kit	26
Transporting sensitive components	27
After working inside your computer	27
BitLocker	
Recommended tools	27
Screw list	28
Major components of Dell Tower EBT2250	28
Chapter 5: Removing and installing Customer Replaceable Units (C	RUs)31
Left-side cover	31
Removing the left-side cover	31
Installing the left-side cover	32
Front cover	33
Removing the front cover	33

Installing the front cover	34
Power button	35
Removing the power button	35
Installing the power button	37
3.5-inch hard drive	38
Removing the 3.5-inch hard drive	38
Installing the 3.5-inch hard drive	4C
Identifying the storage device in Device Manager	41
Identifying the storage device in system setup (BIOS)	41
2.5-inch hard drive	41
Removing the 2.5-inch hard drive	41
Installing the 2.5-inch hard drive	43
Coin-cell battery	45
Removing the coin-cell battery	45
Installing the coin-cell battery	46
Graphics card	47
Removing the graphics card	47
Installing the graphics card	49
Memory module	
Removing the memory modules	
Installing the memory modules	52
Rear-chassis fan	
Removing the rear-chassis fan	
Installing the rear-chassis fan	
Front-chassis fan	
Removing the front-chassis fan	
Installing the front-chassis fan	
Solid state drive (SSD)	
Removing the M.2 2230 solid-state drive	
Installing the M.2 2230 solid-state drive	
Removing the M.2 2280 solid-state drive	
Installing the M.2 2280 solid-state drive	
Wireless card	
Removing the wireless card	
Installing the wireless card	6′
Chapter 6: Removing and installing Field Replaceable Units (FRUs)	
Power-supply unit	
Removing the power-supply unit	
Installing the power-supply unit	
Processor fan and heat-sink assembly	
Removing the processor fan and heat-sink assembly (65 W, air cooling)	
Installing the processor fan and heat-sink assembly (65 W, air cooling)	
Removing the processor fan and heat-sink assembly (125 W, air cooling)	
Installing the processor fan and heat-sink assembly (125 W, air cooling)	
Processor	
Removing the processor	
Installing the processor	
Voltage-regulator heat sink	72 72
removing the voltage-regulator near sink	

Installing the voltage-regulator heat sink	73
System board	74
Removing the system board	74
Installing the system board	78
Chapter 7: Software	83
Operating system	83
Drivers and downloads	83
Chapter 8: BIOS Setup	84
Entering BIOS Setup program	84
Navigation keys	84
One time boot menu	84
F12 One Time Boot menu	85
System setup options	85
Updating the BIOS	96
Updating the BIOS in Windows	96
Updating the BIOS using the USB drive in Windows	97
Updating the BIOS from the One-Time boot menu	97
System and setup password	98
Assigning a System Setup password	98
Deleting or changing an existing system password or setup password	99
Clearing system and setup passwords	99
Chapter 9: Troubleshooting	100
Dell SupportAssist Pre-boot System Performance Check diagnostics	100
Running the SupportAssist Pre-Boot System Performance Check	100
Power-Supply Unit Built-in Self-Test	100
System-diagnostic lights	100
Recovering the operating system	101
Real Time Clock—RTC reset	101
Backup media and recovery options	102
Network power cycle	102
Chapter 10: Getting help and contacting Dell Technologies	103

Views of Dell Tower EBT2250

Front




Figure 1. Front view

1. Power button

Press to turn on the computer if it is turned off, in sleep state, or in hibernate state.

When the computer is turned on, press the power button to put the computer into sleep state; press and hold the power button for 10 seconds to force shut-down the computer.

NOTE: The power-button behavior can be customized in the operating system.

2. SD-card slot

Insert an SD card to expand your storage and store photos, videos, and data from your computer. The computer supports the following card types:

- Secure Digital (SD)
- Secure Digital High Capacity (SDHC)
- Secure Digital Extended Capacity (SDXC)

3. Headset port

Connect headphones or a headset (headphone and microphone combo).

4. USB 3.2 Gen 1 (5 Gbps) ports (2)

Connect devices such as external storage devices and printers. Supports data transfer speeds up to 5 Gbps.

5. USB 3.2 Gen 1 (5 Gbps) port with PowerShare

Connect devices such as external storage devices and printers.

Supports data transfer speeds up to 5 Gbps. PowerShare enables you to charge your USB devices even when your computer is turned off.

- NOTE: If your computer is turned off or in hibernate state, you must connect the power adapter to charge your devices using the PowerShare port. You must enable this feature in the BIOS setup program.
- NOTE: Certain USB devices may not charge when the computer is turned off or in sleep state. In such cases, turn on the computer to charge the device.

6. USB 3.2 Gen 2 (10 Gbps) port with PowerShare

Connect devices such as external storage devices and printers.

Provides data transfer speeds up to 10 Gbps. Supports Power Delivery that enables two-way power supply between devices. Provides up to 15 W power output.

- i NOTE: PowerShare enables you to charge your USB devices even when your computer is turned off.
- NOTE: If a USB device is connected to the PowerShare port before the computer is turned off or put in hibernate state, you must disconnect and connect it again to enable charging.

Back




Figure 2. Back view

1. Back panel

Connect USB, audio, video, and other devices.

2. Service Tag label

The Service Tag is a unique alphanumeric identifier that enables Dell service technicians to identify the hardware components in your computer and access warranty information.

3. PCI-Express X16 (graphics slot 1)

Connect a PCI-Express card such as graphics, audio, or network card to enhance the capabilities of your computer. For optimal graphics performance, use a PCI-Express X16 slot for connecting the graphics card.

- (i) NOTE: The PCI-Express X16 slot works at X8 lanes only.
- NOTE: If you have two graphics cards, the card that is installed in PCI-Express X16 (graphics slot 1) is the primary graphics card.

4. PCI-Express X4 slot

Connect a PCI-Express card such as graphics, audio, or network card to enhance the capabilities of your computer.

i NOTE: The PCI-Express X4 slot 3 works at X2 lanes only.

5. PCI-Express X4 slot

Connect a PCI-Express card such as graphics, audio, or network card to enhance the capabilities of your computer.

i NOTE: The PCI-Express X4 slot 3 works at X2 lanes only.

6. Power port

Connect a power cable to provide power to your computer.

7. Power-supply diagnostics light

Indicates the power-supply state.

8. Padlock rings

Attach a standard padlock to prevent unauthorized access to the interior of your computer.

9. Security-cable slot (for Kensington locks)

Attach a security cable to prevent unauthorized movement of your computer.

Back Panel




Figure 3. Back Panel

1. Hard-drive activity light

The light turns on when the computer reads from or writes to the hard drive.

NOTE: Hard-drive activity light is supported only on computers that are shipped with hard drive.

2. Optical S/PDIF port

Connect an amplifier, speakers, or a TV for digital audio output through an optical cable.

3. Front L/R surround line-out port

Connect audio-output devices such as speakers and amplifiers. In a 5.1 speaker channel setup, connect the front-left and front-right speakers.

4. Line-in port

Connect recording or playback devices such as a microphone or CD player.

5. HDMI 2.0 port

Connect to a TV, external display, or another HDMI-in enabled device. Supports video and audio output.

6. Thunderbolt 4.0 (40 Gbps) port with Power Delivery and DisplayPort

Supports USB4, DisplayPort 1.4, Thunderbolt 4 and also enables you to connect to an external display using a display adapter. Supports data transfer rates of up to 40 Gbps for USB4 and Thunderbolt 4.

- NOTE: You can connect a Dell Docking Station to the Thunderbolt 4 ports. For more information, search in the Knowledge Base Resource at Dell Support Site.
- i NOTE: A USB Type-C to DisplayPort adapter (sold separately) is required to connect a DisplayPort device.
- i) NOTE: USB4 is backward compatible with USB 3.2, USB 2.0, and Thunderbolt 3.
- i NOTE: Thunderbolt 4 supports two 4K displays or one 8K display.

7. USB 3.2 Gen 1 (5 Gbps) ports (2)

Connect devices such as external storage devices and printers. Supports data transfer speeds up to 5 Gbps.

8. USB 2.0 (480 Mbps) ports with Smart Power On (2)

Connect devices such as external storage devices and printers. Provides data transfer speeds up to 480 Mbps.

- NOTE: Deep Sleep is enabled by default. Disable Deep Sleep at the BIOS setup to enable Smart Power On feature on your computer.
- NOTE: Smart Power On is the ability to wake a computer from S4 and S5 sleep states with a move of a mouse or press of a key on the keyboard.
- (i) NOTE: This port does not support video or audio streaming or power delivery.

9. Network port (with lights)

Connect an Ethernet (RJ45) cable from a router or a broadband modem for network or Internet access.

The two lights next to the connector indicate the connectivity status and network activity.

10. USB 2.0 (480 Mbps) ports (2)

Connect devices such as external storage devices and printers. Supports data transfer speeds up to 480 Mbps.

Set up your computer

About this task

(i) NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Steps

1. Connect the wired keyboard and mouse to the available ports. To connect a wireless keyboard and mouse, see the instructions on how to connect in the documentation that ships with the wireless keyboard and mouse.



Figure 4. Connecting the wired keyboard and mouse to your Dell Tower EBT2250

2. Connect to your network using an Ethernet cable.




Figure 5. Connecting the Ethernet cable

3. Connect the display. For more information about setting up the display, see the documentation that is shipped with your display.



Figure 6. Connect the display

4. Connect the power cable to the computer and then connect it to the wall outlet.



Figure 7. Connect the power cable

5. Press the power button at the front of the computer to turn on the computer.



Figure 8. Press the power button

6. Finish the Windows setup.

Follow the on-screen instructions to complete the setup. When setting up, Dell Technologies recommends that you:

• Connect to a network for Windows updates.

- NOTE: If connecting to a secured wireless network, enter the password for the wireless network access when prompted.
- If connected to the Internet, sign-in with or create a Microsoft account. If not connected to the Internet, create an offline account.
- On the **Support and Protection** screen, enter your contact details.
- 7. Locate and use Dell apps from the Windows Start menu—Recommended.

Table 1. Locate Dell apps

Resources	Description		
MyDell			
	MyDell is a software application that offers you a single streamlined engagement platform including account access, device information, and hardware settings. This software delivers intelligent features that automatically fine-tune your computer for the best possible audio, power, and performance. Get the most out of your Dell device with intelligent, personalized technology from MyDell. The following options can be customized in MyDell:		
Desti	 Application Audio Power Color and Display Presence detection 		
	For more information about how to use MyDell, see product guides at Dell Support Site.		
	SupportAssist		
6	SupportAssist proactively and predictively identifies hardware and software issues on your computer and automates the engagement process with Dell Technical support. It addresses performance and stabilization issues, prevents security threats, monitors, and detects hardware failures. For more information, see <i>SupportAssist for Home PCs User's Guide</i> at SupportAssist for Home PCs.		
	i NOTE: In SupportAssist, click the warranty expiry date to renew or upgrade your warranty.		
	Dell Digital Delivery		
	Download software applications, which are purchased but not preinstalled on your computer. For more information about using Dell Digital Delivery, search in the Knowledge Base Resource at Dell Support Site.		

Specifications of Dell Tower EBT2250

Dimensions and weight

The following table lists the height, width, depth, and weight of your Dell Tower EBT2250.

Table 2. Dimensions and weight

Description	Values
Height	372.90 mm (14.68 in.)
Width	173 mm (6.81 in.)
Depth	426.90 mm (16.81 in.)
Weight i NOTE: The weight of your computer depends on the configuration ordered and manufacturing variability.	12.94 kg (28.53 lb)

Processor

The following table lists the details of the processors that are supported for your Dell Tower EBT2250.

Table 3. Processor

Description	Option one	Option two	Option three
Processor type	Intel Core Ultra 5 225	Intel Core Ultra 7 265	Intel Core Ultra 9 285
Processor wattage	65 W	65 W	65 W
Processor total core count	10	20	24
Performance-cores	6	8	8
Efficient-cores	4	12	16
Processor total thread counts i NOTE: Intel Hyper-Threading Technology is only available on Performance-cores.	16	28	32
Processor speed	Up to 4.9 GHz	Up to 5.3 GHz	Up to 5.6 GHz
Performance-cores frequen	су	•	<u> </u>
Processor base frequency	3.3 GHz	2.4 GHz	2.5 GHz
Maximum turbo frequency	4.9 GHz	5.3 GHz	5.6 GHz
Efficient-cores frequency			
Processor base frequency	2.7 GHz	1.8 GHz	1.9 GHz
Maximum turbo frequency	4.4 GHz	4.6 GHz	4.6 GHz
Processor cache 20 MB		30 MB	36 MB
Integrated graphics	Intel Arc Graphics	Intel Arc Graphics	Intel Arc Graphics

Table 4. Processor

Descri	ption	Option four	Option five
Proces	sor type	Intel Core Ultra 7 265K	Intel Core Ultra 9 285K
Proces	sor wattage	125 W	125 W
Proces	sor total core count	20	24
Perfori	mance-cores	8	8
Efficie	nt-cores	12	16
(i) NC	sor total thread counts TE: Intel Hyper-Threading chnology is only available on formance-cores.	28	32
Proces	sor speed	Up to 5.5 GHz	Up to 5.7 GHz
Perfori	mance-cores frequency	<u> </u>	<u> </u>
	Processor base frequency	3.9 GHz	3.7 GHz
	Maximum turbo frequency	5.5 GHz	5.7 GHz
Efficie	nt-cores frequency	•	<u>'</u>
	Processor base frequency	3.3 GHz	3.2 GHz
	Maximum turbo frequency	4.6 GHz	4.6 GHz
Proces	sor cache	30 MB	36 MB
Integrated graphics		Intel Arc Graphics	Intel Arc Graphics

Chipset

The following table lists the details of the chipset that is supported by your Dell Tower EBT2250.

Table 5. Chipset

Description	Values
Chipset	Z890
Processor	Intel Core Ultra 5/7/9Intel Core Ultra 7K/9K
DRAM bus width	128-bit
Flash EPROM	32 MB
PCle bus	Up to Gen5

Operating system

Your Dell Tower EBT2250 supports the following operating systems:

- Windows 11 Pro, 64-bit
- Windows 11 Home, 64-bit

Memory

The following table lists the memory specifications that are supported by your Dell Tower EBT2250.

Table 6. Memory specifications

Description	Values	
Memory slots	2	
Memory type	DDR5	
Memory speed	5200 MT/s	
Maximum memory configuration	64 GB	
Minimum memory configuration	8 GB	
Memory size per slot	8 GB, 16 GB, 32 GB	
Memory configurations supported	 8 GB, 1 x 8 GB, DDR5, 5200 MT/s 16 GB, 1 x 16 GB, DDR5, 5200 MT/s 16 GB, 2 x 8 GB, DDR5, 5200 MT/s, dual-channel 32 GB, 1 x 32 GB, DDR5, 5200 MT/s 32 GB, 2 x 16 GB, DDR5, 5200 MT/s, dual-channel 64 GB, 2 x 32 GB, DDR5, 5200 MT/s, dual-channel 	

Ports and connectors

The following table lists the external and internal ports available on your Dell Tower EBT2250.

Table 7. Ports and connectors

Description	Values
External:	
Network	One RJ45 port
USB	 Two USB 3.2 Gen 1 (5 Gbps) ports (front) One USB 3.2 Gen 1 (5 Gbps) port with PowerShare (front) One USB 3.2 Gen 2 (10 Gbps) Type-C port with PowerShare (front) Two USB 2.0 (480 Mbps) ports with Smart Power On (rear) Two USB 2.0 (480 Mbps) ports (rear) Two USB 3.2 Gen 1 (5 Gbps) ports (rear) One Thunderbolt 4 (40 Gbps) port with DisplayPort Alt Mode/USB Type-C/USB4/Power Delivery (rear)
Audio	 One front headset port One rear line-out port One rear line-in port One rear optical S/PDIF port

Table 7. Ports and connectors (continued)

Description	Values	
Video	One HDMI 2.0 port	
Media-card reader	One SD-card slot	
Power port	One AC power-supply port	
Security	One security-cable slot (for Kensington locks)One padlock slot	
Internal:		
PCIe expansion card slots	 One PCle x16 mechanical/x16 electrical Gen5 slot Two PCle Gen3 x4 slots 	
mSATA	Not supported	
SATA	Three SATA slots	
M.2	 One M.2 2230 slot for WiFi and Bluetooth combo card Two M.2 2230 or 2280 slots for solid-state drives 	
	NOTE: To learn more about the features of different types of M.2 cards, search in the Knowledge Base Resource at Dell Support Site.	

Ethernet

The following table lists the wired Ethernet Local Area Network (LAN) specifications of your Dell Tower EBT2250.

Table 8. Ethernet specifications

Description	Values
Model	Killer E3100G Ethernet controller integrated on the system board
Transfer rate	10/100/1000/2500 Mbps

Wireless module

The following table lists the Wireless Local Area Network (WLAN) module that is supported on your Dell Tower EBT2250.

Table 9. Wireless module specifications

Description	Values
Model number	Intel BE200
Transfer rate	Up to 5760 Mbps
Frequency bands supported	2.4 GHz/5 GHz/6 GHz
Wireless standards	 WiFi 802.11a/b/g Wi-Fi 4 (WiFi 802.11n) Wi-Fi 5 (WiFi 802.11ac)

Table 9. Wireless module specifications (continued)

Description	Values
	Wi-Fi 6E (WiFi 802.11ax)Wi-Fi 7 (WiFi 802.11be)
Encryption	64-bit/128-bit WEP AES-CCMP TKIP
Bluetooth wireless card	Bluetooth 5.4 wireless card

Storage

This section lists the storage options on your Dell Tower EBT2250.

Your Dell Tower EBT2250 supports one of the following storage configurations:

- Up to two M.2 2230 or M.2 2280 PCle NVMe solid-state drives
- Up to two M.2 2230 or M.2 2280 PCle NVMe solid-state drives, and up to two 3.5-inch hard drives The primary drive of your Dell Tower EBT2250 varies with the storage configuration. For computers:
- With a M.2 drive, the M.2 drive is the primary drive.
- With a M.2 drive and up to two hard-disk drives, the M.2 drive is the primary drive.

Table 10. Storage specifications

Storage type	Interface type	Capacity
One M.2 2230 solid-state drive	PCle Gen4 x4 NVMe, up to 64 Gbps	Up to 512 GB
One M.2 2280 solid-state drive	PCle Gen4 x4 NVMe, up to 64 Gbps	Up to 4 TB
Two 3.5-inch hard-disk drives	SATA AHCI, up to 6 Gbps	Up to 2 TB
Two 2.5-inch hard-disk drives	SATA AHCI, up to 6 Gbps	Up to 2 TB

GPU—Integrated

The following table lists the specifications of the integrated Graphics Processing Unit (GPU) supported by your Dell Tower EBT2250.

Table 11. GPU—Integrated

Controller	Memory size	Processor
Intel Arc Graphics	Shared system memory	Intel Core Ultra 5/7/9
Intel Arc Graphics	Shared system memory	Intel Core Ultra 7K/9K

Video

Table 12. Discrete graphics specifications

Discrete graphics							
Controller	Number of cards	External display support	Memory size	Memory type	PCIe version	Power consumption	Recommended PSU
NVIDIA GeForce RTX 3050	1	Three DisplayPort 1.4 ports, one HDMI 2.1 port	8 GB	GDDR6	4	120 W	>= 460 W
NVIDIA GeForce RTX 4060	1	Three DisplayPort 1.4 ports, one HDMI 2.1 port	8 GB	GDDR6	4	115 W	>= 460 W
NVIDIA GeForce RTX 4060 Ti	1	Three DisplayPort 1.4 ports, one HDMI 2.1 port	8 GB	GDDR6	4	160 W	>= 460 W
NVIDIA GeForce RTX 4070 SUPER	1	Three DisplayPort 1.4 ports, one HDMI 2.1 port	12 GB	GDDR6X	4	220 W	>= 750 W
NVIDIA GeForce RTX 4070 Ti SUPER	1	Three DisplayPort 1.4 ports, one HDMI 2.1 port	16 GB	GDDR6X	4	285 W	>= 750 W
NVIDIA GeForce RTX 4080 SUPER	1	Three DisplayPort 1.4 ports, one HDMI 2.1 port	16 GB	GDDR6X	4	320 W	>= 750 W
NVIDIA GeForce RTX 4090	1	Three DisplayPort 1.4 ports, one HDMI 2.1 port	24 GB	GDDR6X	4	450 W	>= 1000 W

Audio

The following table lists the audio specifications of your Dell Tower EBT2250.

Table 13. Audio specifications

Description	Values
Audio type	Integrated 7.1 channel audio

Table 13. Audio specifications (continued)

Description	Values	
Audio controller	Realtek ALC1220	
Internal audio interface	High definition audio interface	
External audio interface	 Headset port - 3.5 mm Universal audio jack Front L/R surround line-out port - 3.5 mm Line-in port - 3.5 mm 	

Media-card reader

The following table provides the specification of media cards that are supported by your Dell Tower EBT2250.

Table 14. Media-card reader specifications

Description	Values	
Media-card slot type	One SD card slot	
Media-cards supported	 Secure Digital (SD) Secure Digital High Capacity (SDHC) Secure Digital Extended Capacity (SDXC) 	
(i) NOTE: The maximum capacity that is supported by the media-card reader varies depending on the standard of the media card that is installed on your computer.		

Power ratings

The following table lists the power rating specifications of Dell Tower EBT2250.

Table 15. Power ratings

Description	Option one	Option two	Option three
Туре	460 W Bronze	750 W Platinum	1000 W Platinum
Input voltage	90 VAC to 264 VAC	90 VAC to 264 VAC	90 VAC to 264 VAC
Input frequency	47 Hz to 63 Hz	47 Hz to 63 Hz	47 Hz to 63 Hz
Input current (maximum)	7 A	10 A	13.6 A
Output current (continuous)	Operating: 12 VA/18 A 12 VB/18 A 12 VC/18 A Standby: 12 VA/1.5 A 12 VB /3.3 A 12 VC/0 A	Operating: 12 VA/36 A 12 VB/27 A 12 VC/36 A Standby: 12 VA/1.5 A 12 VB /5 A	Operating: 12 VA/36 A 12 VB/27 A 12 VC/36 A Standby: 12 VA/1.5 A 12 VB /5 A
Rated output voltage	+ 12 VA+ 12 VB+ 12 VC	 + 12 VA + 12 VB + 12 VC 	 + 12 VA + 12 VB + 12 VC

Table 15. Power ratings (continued)

Description		Option one	Option two	Option three
Те	emperature range:			
	Operating	5°C to 45°C (41°F to 113°F)	5°C to 50°C (41°F to 122°F)	5°C to 50°C (41°F to 122°F)
	Storage	-40°C to 70°C (-40°F to 158°F)	-40°C to 70°C (-40°F to 158°F)	-40°C to 70°C (-40°F to 158°F)

Power supply connector

The following table lists the power-supply connectors of your computer.

Table 16. Power supply connector

Power-supply unit	Power-supply unit connecters
460 W Bronze	 Two four-pin connectors for the processor One eight-pin connector for the system board One six-pin and one (6+2) pin connector for graphics card
750 W Platinum	 Two four-pin connectors for the processor One 10-pin connector for the system board Two six-pin and one (6+2) pin connector for graphics card
1000 W Platinum	 Two four-pin connectors for the processor One 10-pin connector for the system board Two six-pin and one (6+2) pin connector for graphics card

Operating and storage environment

This table lists the operating and storage specifications of your Dell Tower EBT2250.

Airborne contaminant level: G1 as defined by ISA-S71.04-1985

Table 17. Computer environment

Description	Operating	Storage
Temperature range	10°C to 35°C (50°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	20% to 80% (non-condensing)	5% to 95% (non-condensing)
Vibration (maximum)*	0.26 GRMS	1.37 GRMS
Shock (maximum)	40 G†	105 G†
Altitude range	-15.20 m to 3048 m (-49.87 ft to 10000 ft)	-15.20 m to 10668 m (-49.87 ft to 35000 ft)

CAUTION: Operating and storage temperature ranges may differ among components, so operating or storing the device outside these ranges may impact the performance of specific components.

^{*} Measured using a random vibration spectrum that simulates the user environment.

[†] Measured using a 2 ms half-sine pulse.

Working inside your computer

Safety instructions

Use the following safety guidelines to protect your computer from potential damage and to ensure your personal safety. Unless otherwise noted, each procedure in this document assumes that you have read the safety information that shipped with your computer.

- WARNING: Before working inside your computer, read the safety information that is shipped with your computer. For more safety best practices, see Dell Regulatory Compliance Home Page.
- WARNING: Disconnect your computer from all power sources before opening the computer cover or panels. After you finish working inside the computer, replace all covers, panels, and screws before connecting your computer to an electrical outlet.
- CAUTION: To avoid damaging the computer, ensure that the work surface is flat, dry, and clean.
- CAUTION: You should only perform troubleshooting and repairs as authorized or directed by the Dell technical support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. See the safety instructions that are shipped with the product or at Dell Regulatory Compliance Home Page.
- CAUTION: Before touching anything inside your computer, ground yourself by touching an unpainted metal surface, such as the metal at the back of the computer. While you work, periodically touch an unpainted metal surface to dissipate static electricity which could harm internal components.
- CAUTION: To avoid damaging the components and cards, handle them by their edges, and avoid touching the pins and the contacts.
- CAUTION: When you disconnect a cable, pull it by its connector or its pull tab, not the cable itself. Some cables have connectors with locking tabs or thumbscrews that you must disengage before disconnecting the cable. When disconnecting cables, keep them evenly aligned to avoid bending the connector pins. When connecting cables, ensure that the connector on the cable is correctly oriented and aligned with the port.
- igtriangle CAUTION: Press and eject any installed card from the media-card reader.
- CAUTION: Exercise caution when handling rechargeable Li-ion batteries in laptops. Swollen batteries should not be used and should be replaced and disposed properly.

Before working inside your computer

About this task

i NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Steps

- 1. Save and close all open files and exit all open applications.
- 2. Shut down your computer. For Windows operating system, click Start > **U** Power > Shut down.
 - NOTE: If you are using a different operating system, see the documentation of your operating system for shut-down instructions.
- 3. Turn off all the attached peripherals.
- 4. Disconnect your computer and all attached devices from their electrical outlets.

5. Disconnect all attached network devices and peripherals, such as keyboard, mouse, and monitor from your computer.

CAUTION: To disconnect a network cable, unplug the cable from your computer.

6. Remove any media card and optical disc from your computer, if applicable.

Safety precautions

This section details the primary steps to be followed before performing any disassembly instructions.

Observe the following safety precautions before you perform any installation or break-fix procedures involving disassembly or reassembly:

- Turn off the computer and all attached peripherals.
- Disconnect the computer from AC power.
- Disconnect all network cables and peripherals from the computer.
- Use an ESD field service kit when working inside any to avoid electrostatic discharge (ESD) damage.
- Place the removed component on an anti-static mat after removing it from the computer.
- Wear shoes with nonconductive rubber soles to reduce the chance of getting electrocuted.
- Unplugging, pressing, and holding the power button for 15 seconds should discharge residual power in the system board.

Standby power

Dell products with standby power must be unplugged before you open the back cover. Systems that are equipped with standby power are powered while turned off. The internal power enables the computer to be remotely turned on (Wake-on-LAN) and suspended into a sleep mode and has other advanced power management features.

Bonding

Bonding is a method for connecting two or more grounding conductors to the same electrical potential. This is done by using a field service electrostatic discharge (ESD) kit. When connecting a bonding wire, ensure that it is connected to bare metal and never to a painted or nonmetal surface. Ensure that the wrist strap is secure and in full contact with your skin. Remove all jewelry, watches, bracelets, or rings before grounding yourself and the equipment.

Electrostatic discharge—ESD protection

ESD is a major concern when you handle electronic components, especially sensitive components such as expansion cards, processors, memory modules, and system boards. A slight charge can damage circuits in ways that may not be obvious, such as intermittent problems or a shortened product life span. As the industry pushes for lower power requirements and increased density, ESD protection is an increasing concern.

Two recognized types of ESD damage are catastrophic and intermittent failures.

- Catastrophic Catastrophic failures represent approximately 20 percent of ESD-related failures. The damage causes
 an immediate and complete loss of device functionality. An example of catastrophic failure is a memory module that has
 received a static shock and immediately generates a "No POST/No Video" symptom with a beep code that is emitted for
 missing or nonfunctional memory.
- Intermittent Intermittent failures represent approximately 80 percent of ESD-related failures. The high rate of intermittent failures means that most of the time when damage occurs, it is not immediately recognizable. The memory module receives a static shock, but the tracing is merely weakened and does not immediately produce outward symptoms that are related to the damage. The weakened trace may take weeks or months to melt, and in the meantime may cause degradation of memory integrity, intermittent memory errors, and so on.

Intermittent failures that are also called latent or "walking wounded" are difficult to detect and troubleshoot.

Perform the following steps to prevent ESD damage:

- Use a wired ESD wrist strap that is properly grounded. Wireless anti-static straps do not provide adequate protection. Touching the chassis before handling parts does not ensure adequate ESD protection on parts with increased sensitivity to ESD damage.
- Handle all static-sensitive components in a static-safe area. If possible, use anti-static floor pads and workbench pads.
- When unpacking a static-sensitive component from its shipping carton, do not remove the component from the anti-static packing material until you are ready to install the component. Before unwrapping the anti-static packaging, use the anti-

static wrist strap to discharge the static electricity from your body. For more information about the wrist strap and ESD wrist strap tester, see Components of an ESD Field Service Kit.

• Before transporting a static-sensitive component, place it in an anti-static container or packaging.

ESD Field Service kit

The unmonitored field service kit is the most commonly used service kit. Each Field Service kit includes three main components: anti-static mat, wrist strap, and bonding wire.

CAUTION: It is critical to keep ESD-sensitive devices away from internal parts that are insulated and often highly charged, such as plastic heat sink casings.

Working Environment

Before deploying the ESD Field Service kit, assess the situation at the customer location. For example, deploying the kit for a server environment is different than for a desktop or laptop environment. Servers are typically installed in a rack within a data center; desktops or laptops are typically placed on office desks or cubicles. Always look for a large open flat work area that is free of clutter and large enough to deploy the ESD kit with additional space to accommodate the type of computer that is being repaired. The workspace should also be free of insulators that can cause an ESD event. On the work area, insulators such as styrofoam and other plastics should always be moved at least 12 inches or 30 centimeters away from sensitive parts before physically handling any hardware components.

ESD Packaging

All ESD-sensitive devices must be shipped and received in static-safe packaging. Metal, static-shielded bags are preferred. However, you should always return the damaged component using the same ESD bag and packaging that the new part arrived in. The ESD bag should be folded over and taped shut and all the same foam packing material should be used in the original box that the new part arrived in. ESD-sensitive devices should be removed from packaging only at an ESD-protected work surface, and parts should never be placed on top of the ESD bag because only the inside of the bag is shielded. Always place parts in your hand, on the anti-static mat, in the computer, or inside an ESD bag.

Components of an ESD Field Service kit

The components of an ESD Field Service kit are:

- Anti-Static Mat The anti-static mat is dissipative and parts can be placed on it during service procedures. When using an anti-static mat, your wrist strap should be snug and the bonding wire should be connected to the anti-static mat and to any bare metal on the computer being worked on. Once deployed properly, service parts can be removed from the ESD bag and placed directly on the anti-static mat. ESD-sensitive items are safe in your hand, on the anti-static mat, in the computer, or inside an ESD bag.
- Wrist Strap and Bonding Wire The wrist strap and bonding wire can be either directly connected between your wrist and bare metal on the hardware if the anti-static mat is not required, or connect to the anti-static mat to protect hardware that is temporarily placed on the mat. The physical connection of the wrist strap and bonding wire between your skin, the anti-static mat, and the hardware is known as bonding. Use only Field Service kits with a wrist strap, anti-static mat, and bonding wire. Never use wireless wrist straps. Always be cautious that the internal wires of a wrist strap are prone to damage from normal wear and tear, and must be checked regularly with a wrist strap tester in order to avoid accidental ESD hardware damage. It is recommended to test the wrist strap and bonding wire at least once per week.
- ESD Wrist Strap Tester The wires inside an ESD strap are prone to damage over time. When using an unmonitored kit, it is a best practice to regularly test the strap prior to each service, and at a minimum, test once per week. A wrist strap tester is the best method for doing this test. To perform the test, plug the bonding-wire of the wrist-strap into the tester while it is strapped to your wrist and push the button to test. A green LED is lit if the test is successful; a red LED is lit and an alarm sounds if the test fails.
- NOTE: It is recommended to always use the traditional wired ESD grounding wrist strap and protective anti-static mat when servicing Dell products. In addition, it is critical to keep sensitive parts separate from all insulator parts while servicing the computer.

Transporting sensitive components

When transporting ESD sensitive components such as replacement parts or parts to be returned to Dell, it is critical to place these parts in anti-static bags for safe transport.

Lifting equipment

Adhere to the following guidelines when lifting heavy equipment:

CAUTION: Do not lift greater than 50 pounds. Always obtain additional resources or use a mechanical lifting device.

- 1. Get a firm balanced footing. Keep your feet apart for a stable base, and point your toes out.
- 2. Tighten stomach muscles. Abdominal muscles support your spine when you lift, offsetting the force of the load.
- 3. Lift with your legs, not your back.
- 4. Keep the load close. The closer it is to your spine, the less force it exerts on your back.
- 5. Keep your back upright, whether lifting or setting down the load. Do not add the weight of your body to the load. Avoid twisting your body and back.
- 6. Follow the same technique in reverse to set the load down.

After working inside your computer

About this task

igwedge CAUTION: Leaving stray or loose screws inside your computer may severely damage your computer.

Steps

- 1. Replace all screws and ensure that no stray screws remain inside your computer.
- 2. Connect any external devices, peripherals, or cables you removed before working on your computer.
- 3. Replace any media cards, discs, or any other components that you removed before working on your computer.
- 4. Connect your computer and all attached devices to their electrical outlets.
- 5. Turn on your computer.

BitLocker

CAUTION: If BitLocker is not suspended before updating the BIOS, the BitLocker key is not recognized the next time you reboot the computer. You will then be prompted to enter the recovery key to progress, and the system displays a prompt for the recovery key on each reboot. If the recovery key is not known, this can result in data loss or an operating system reinstall. For more information, see Knowledge Article: updating the BIOS on Dell systems with BitLocker enabled.

The installation of the following components triggers BitLocker:

- Hard disk drive or solid-state drive
- System board

Recommended tools

The procedures in this document may require the following tools:

- Phillips screwdriver #2
- Phillips screwdriver #1
- Plastic scribe

Screw list

- (i) **NOTE:** When removing screws from a component, it is recommended to note the screw type and the quantity of screws, and then place them in a screw storage box. This is to ensure that the correct number of screws and correct screw type is restored when the component is replaced.
- NOTE: Some computers have magnetic surfaces. Ensure that the screws are not left attached to such surfaces when replacing a component.
- i NOTE: Screw color may vary depending on the configuration ordered.

Table 18. Screw list

Component	Screw type	Quantity	Image
Side cover	#6-32 (Captive screw)	1	7
Power button	#6-32	1	
Rear-chassis fan	M3x5	1	
Front-chassis fan	M3x5	1	
M.2 2230 solid-state drive	M2x3.5	1	
M.2 2280 solid-state drive	M2x3.5	1	
Wireless card	M2x3.5	1	
Power-supply unit	#6-32	6	
System board	#6-32	10	

Major components of Dell Tower EBT2250

The following image shows the major components of Dell Tower EBT2250.




Figure 9. Major components of Dell Tower EBT2250

1. Left-side cover

- 2. Hard-drive carrier
- 3. Hard drive
- 4. Graphics-card middle holder
- 5. Graphics card
- 6. Power button and power-button bracket
- 7. System board
- 8. Chassis
- 9. Graphics-card end holder
- 10. Front I/O-bracket
- 11. Front cover
- 12. Antenna module (1)
- 13. Antenna module (2)
- 14. Power-supply unit
- 15. Power-supply cage
- 16. Memory module
- 17. M.2 2230 solid-state drive
- 18. Wireless card
- 19. Voltage-regulator heat sink
- 20. Fan and heat-sink assembly
- 21. Rear-chassis fan
- 22. Front-chassis fan
- (i) NOTE: Dell Technologies provides a list of components and their part numbers for the original system configuration purchased. These parts are available according to warranty coverages purchased by the customer. Contact your Dell sales representative for purchase options.

Removing and installing Customer Replaceable Units (CRUs)

The replaceable components in this chapter are Customer Replaceable Units (CRUs).

CAUTION: Customers can replace only the Customer Replaceable Units (CRUs) following the safety precautions and replacement procedures.

i NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Left-side cover

Removing the left-side cover

Prerequisites

1. Follow the procedure in Before working inside your computer.

About this task

The following image(s) indicate the location of the left-side cover and provides a visual representation of the removal procedure.





Figure 10. Removing the left-side cover

Steps

- 1. Using a flat head or Phillips-head screwdriver, loosen the captive screw that secures the left-side cover latch to the chassis.
- 2. Pull on the left-side cover latch to release the left-side cover from the chassis.
- **3.** Holding the left-side cover firmly on both sides, remove and lift the left-side cover from the chassis.

Installing the left-side cover

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the left-side cover and provides a visual representation of the installation procedure.





Figure 11. Installing the left-side cover

Steps

- 1. Hold the left-side cover firmly on both sides, slide the bottom edge of the left-side cover into the chassis.
- 2. Holding the left-side cover latch, push the left-side cover into position.
- 3. Using a flat head or Phillips-head screwdriver, tighten the captive screw that secures the left-side cover latch to the chassis.

Next steps

1. Follow the procedure in After working inside your computer.

Front cover

Removing the front cover

Prerequisites

1. Follow the procedure in Before working inside your computer.

2. Remove the left-side cover.

About this task

The following image(s) indicate the location of the front cover and provides a visual representation of the removal procedure.






Figure 12. Removing the front cover

Steps

- 1. Gently pry and release the front-cover tabs from the top, working down sequentially to the bottom-left tab.
- 2. Swing the front cover outwards, away from the chassis, and remove the cover.

Installing the front cover

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the front cover and provides a visual representation of the installation procedure.






Figure 13. Installing the front cover

Steps

- 1. Insert the right-side front-cover tabs into the corresponding slots on the chassis.
- 2. Push the left-side of the front cover towards the chassis, snapping the tabs into position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Power button

Removing the power button

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

3. Remove the front cover.

About this task

The following image(s) indicate the location of the power button and provides a visual representation of the removal procedure.




Figure 14. Removing the power button




Figure 15. Removing the power button

Steps

1. Place the computer on its side with the left side facing up.

- 2. Disconnect the power-button cable from its connector (PWR SW1) on the system board.
- 3. Remove the screw (#6-32) that secures the power-button bracket to the chassis.
- **4.** Remove the power button and its bracket from the slot on the chassis and thread the power-button cable through the slot on the chassis.
- 5. Press the release tabs on the sides of the power button to release it from the power-button bracket. If necessary, use the flat-side of a scribe to lever the power button off the bracket.
- **6.** Thread the power-button cable through the slot on the power-button bracket.

Installing the power button

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the power button and provides a visual representation of the installation procedure.




Figure 16. Installing the power button




Figure 17. Installing the power button

- 1. Thread the power-button cable through the slot on the power-button bracket.
- 2. Press down on the securing tabs to push the power button into the slot on the power-button bracket.
- 3. Thread the power-button cable through the slot on the chassis.
- **4.** Insert the top tabs on the power-button bracket into the slot in the chassis, then align the screw hole on the bracket with the screw hole on the chassis.
- 5. Replace the screw (#6-32) that secures the power-button bracket to the chassis.
- 6. Connect the power-button cable to its connector (PWR SW1) on the system board.
- 7. Place the computer in an upright position.

Next steps

- 1. Install the front cover.
- 2. Install the left-side cover.
- **3.** Follow the procedure in After working inside your computer.

3.5-inch hard drive

Removing the 3.5-inch hard drive

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

NOTE: This computer may have up to two 3.5-inch hard drives installed in the two hard-drive cages (HDD0 and HDD1) on the chassis.

The following image(s) indicate the location of the 3.5-inch hard drive in the HDD0 hard-drive cage and provides a visual representation of the removal procedure.




Figure 18. Removing the 3.5-inch hard drive

Steps

- 1. Place the computer on its side with the left side facing up.
- 2. Disconnect the hard-drive data and power cables from the 3.5-inch hard drive.
- 3. Press the release tabs on the hard-drive carrier and slide the hard-drive carrier out of the hard-drive cage.
- **4.** Pry the hard-drive carrier to release the tabs on the carrier from the slots on the 3.5-inch hard drive.
- **5.** Lift the 3.5-inch hard drive off the hard-drive carrier.
 - (i) NOTE: Repeat step 2 to step 5 to remove the 3.5-inch hard drive from the HDD1 hard-drive cage.
 - NOTE: Note the orientation of the hard drive so that you can replace it correctly.

Installing the 3.5-inch hard drive

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

- NOTE: You may install two 3.5-inch hard drives into your computer, one into each hard-drive cage (HDD0 and HDD1) on the chassis.
- NOTE: Be sure to use the correct size hard-drive carrier for the hard-drive to be installed. For example, use a 3.5-inch hard-drive carrier to install a 3.5-inch hard drive. If you do not have the correct size hard-drive carrier, order one from Dell.

The following image(s) indicate the location of the 3.5-inch hard drive in the HDD0 hard-drive cage and provides a visual representation of the installation procedure.




Figure 19. Installing the 3.5-inch hard drive

Steps

- 1. Noting the orientation of the hard drive and carrier in the image, place the 3.5-inch hard drive into the hard-drive carrier.
- 2. Flex the carrier on the sides to ensure the pins on the carrier fit snugly into the screw holes on the sides of the hard drive.

- **3.** Holding the hard-drive assembly securely, flip it around so that the top of the hard drive faces the bottom of the hard-drive cage as illustrated. Push the hard-drive assembly into the hard-drive cage until it locks into place.
- 4. Connect the hard-drive data cable and power cable to the 3.5-inch hard drive.
 - (i) NOTE: Repeat step 1 to step 4 to install the 3.5-inch hard drive in the HDD1 hard-drive cage.
- 5. Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.
- 3. Verify if the storage device is installed correctly (optional). You can verify by following the steps in Identifying storage device in device manager or Identifying your storage device in system setup (BIOS).
- NOTE: To install the operating system on to your storage device, see Reinstall Windows to the Dell factory image using recovery media in the Knowledge Base Resource at Dell Support Site.

Identifying the storage device in Device Manager

Steps

- 1. On the taskbar, click the search box, and then type Device Manager.
- Click Device Manager. The Device Manager window is displayed.
- 3. Expand Disk drives.

Identifying the storage device in system setup (BIOS)

Steps

- 1. Turn on or restart your computer.
- 2. Press F2 when the Dell logo is displayed on the screen to enter the BIOS setup program. A list of hard drives are displayed under the **System Information** in the **General** group.

2.5-inch hard drive

Removing the 2.5-inch hard drive

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

NOTE: This computer may have up to two 2.5-inch hard drives installed in the two hard-drive cages (HDD0 and HDD1) on the chassis.

The following images indicate the location of the 2.5-inch hard drive in the HDD0 hard-drive cage and provide a visual representation of the removal procedure.



Figure 20. Removing the 2.5-inch hard drive




Figure 21. Hard drive and hard-drive carrier drive

1. Disconnect the data and power cables from the hard drive.

- 2. Press the release tabs on the hard-drive carrier and slide the hard-drive carrier out of the hard-drive cage.
- 3. Pry the sides of the hard-drive carrier to release the tabs on the carrier from the slots on the hard drive.
- **4.** Lift the hard drive out of the hard-drive carrier.
 - (i) NOTE: Repeat step 1 to step 4 to remove the 2.5-inch hard drive from the HDD1 hard-drive cage.
 - i NOTE: Note the orientation of the hard drive so that you can replace it correctly.

Installing the 2.5-inch hard drive

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

NOTE: Be sure to use the correct size hard-drive carrier for the hard-drive to be installed. For example, use a 2.5-inch hard-drive carrier to install a 2.5-inch hard drive. If you do not have the correct size hard-drive carrier, order one from Dell.

The following images indicate the location of the 2.5-inch hard drive and provide a visual representation of the installation procedure.




Figure 22. Installing the 2.5-inch hard drive



Figure 23. Installing the 2.5-inch hard drive

(i) NOTE: Note the orientation on the hard-drive carrier to replace it correctly.

- 1. Align the hard drive with the pins on the hard-drive carrier.
- 2. Using the tabs on the opposite side, flex open the carrier to insert the pins on the other side.
- 3. Slide the hard-drive assembly into the hard-drive cage until it snaps into place.
- 4. Connect the data and power cables to the hard drive.
 - (i) NOTE: Repeat step 1 to step 4 to install the 2.5-inch hard drive in the HDD1 hard-drive cage.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.
- 3. Verify if the storage device is installed correctly (optional). You can verify by following the steps in Identifying storage device in device manager or Identifying your storage device in system setup (BIOS).
- NOTE: To install the operating system on to your storage device, see Reinstall Windows to the Dell factory image using recovery media in the Knowledge Base Resource at Dell Support Site.

Coin-cell battery

Removing the coin-cell battery

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
 - WARNING: This computer contains a coin-cell battery and requires trained technicians for handling guidance.
 - CAUTION: Removing the coin-cell battery clears the CMOS and reset BIOS settings.
- 2. Remove the left-side cover.

About this task

The following images indicate the location of the coin-cell battery and provide a visual representation of the removal procedure.






Figure 24. Removing the coin-cell battery

- 1. Place the computer on its side with the left side facing up.
- 2. Push the coin-cell battery-release lever on the coin-cell battery socket (BT1) to release the coin-cell battery out of the socket.
- 3. Remove the coin-cell battery.

Installing the coin-cell battery

MARNING: This computer contains a coin-cell battery and requires trained technicians for handling guidance.

CAUTION: Removing the coin-cell battery clears the CMOS and reset BIOS settings.

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the coin-cell battery and provides a visual representation of the installation procedure.






Figure 25. Installing the coin-cell battery

- 1. Insert the coin-cell battery into the socket (BT1) with the positive side (+) label facing up and snap the battery in the socket.
- 2. Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Graphics card

Removing the graphics card


Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

NOTE: Depending on the configuration ordered, your computer may not have a discrete graphics card installed.

The following image(s) indicate the location of the graphics card and provides a visual representation of the removal procedure.






Figure 26. Removing the graphics card



Figure 27. Removing the graphics card

- 1. Place the computer on its side with the left side facing up.
- 2. Slide the release latch to its unlock position and lift the graphics-card end holder away from the front-chassis fan.
 - i NOTE: Skip this step if your graphics card does not ship with a graphics-card end holder.
- 3. Press and hold the securing clip on the graphics-card power cable, then pull the connector off the graphics card.
- 4. Slide and hold the locking mechanism on the graphics-card support bracket, then pull the bracket off the retaining rails on the power-supply cage.
 - NOTE: The size and location of the graphic-card support bracket may vary depending on the graphics card configuration on your computer.
 - (i) NOTE: Skip this step if your graphics card does not ship with a graphics-card support bracket.
- 5. Lift the pull tab and open the expansion-card door.
- 6. Push the securing tab on the PCle slot away from the graphics card, grasp the card by its top corner, and ease it out of the slot.

Installing the graphics card

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the graphics card and provides a visual representation of the installation procedure.






Figure 28. Installing the graphics card




Figure 29. Installing the graphics card

- 1. Place the card into the PCle slot and press down firmly until the graphics card snaps into place.
- 2. Close the expansion-card door and snap the latch back into position.
- 3. Insert the graphics-card support bracket onto the retaining rails and slide the latch to its lock position.
 - i NOTE: Skip this step if your graphics card does not ship with a graphics-card end holder.
 - NOTE: The size and location of the graphic-card support bracket may vary depending on the graphics card configuration on your computer.
- 4. Connect the graphics-card power cable to the graphics card.
- 5. Align and place the graphics-card end holder on the chassis and slide the latch to its lock position.
 - NOTE: Skip this step if your graphics card does not ship with a graphics-card end holder.
- 6. Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Memory module

Removing the memory modules


Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

i NOTE: This computer may have up to two memory modules installed in the memory-module slots (DIMM1 and DIMM2).

The following image(s) indicate the location of the memory and provides a visual representation of the removal procedure.






Figure 30. Removing the memory

Steps

1. CAUTION: To prevent damage to the memory module, hold the memory module by the edges. Do not touch the components or metallic contacts on the memory module as ESD can inflict severe damage on the components. To read more about ESD protection, see ESD protection.

Place the computer on its side with the left side facing up.

- 2. Carefully spread apart the securing-clips on each end of the memory-module slot (DIMM1).
- 3. Grasp the memory module near the securing clip, and then gently ease the memory module out of the memory-module slot.
 - NOTE: Note the slot and the orientation of the memory module in order to replace it in the correct slot.
 - NOTE: If the memory module is difficult to remove, gently ease the memory module back and forth to remove it from the slot.
 - NOTE: Repeat step 2 to step 3 to remove any other memory module installed in the other memory-module slot (DIMM2).

Installing the memory modules


Prerequisites


If you are replacing a component, remove the existing component before performing the installation process.

About this task

i NOTE: Up to two memory modules may be installed into this computer.

The following images indicate the location of the memory and provide a visual representation of the installation procedure.








Figure 31. Installing the memory

Steps

1. CAUTION: To prevent damage to the memory module, hold the memory module by the edges. Do not touch the components or metallic contacts on the memory module as ESD can inflict severe damage on the components. To read more about ESD protection, see ESD protection.

Align the notch on the memory module with the tab on the memory-module slot (DIMM1).

- 2. Insert the memory module into the memory-module slot (DIMM1).
- 3. Press down on the memory module until the memory module snaps into position and the securing clip locks in place.
 - NOTE: The securing clips return to the locked position. If you do not hear the click, remove the memory module and reinstall it.
 - NOTE: If the memory module is difficult to remove, gently ease the memory module back and forth to remove it from the slot.
 - NOTE: Repeat step 1 to step 3 for any other memory module to be installed in the other memory-module slot (DIMM2).
 - NOTE: To enable dual-channel memory support when installing two identical memory modules, insert one module into the DIMM1 slot and the other module into the DIMM2 slot.
- **4.** Place the computer in an upright position.

Next steps

1. Install the left-side cover.

2. Follow the procedure in After working inside your computer.

Rear-chassis fan

Removing the rear-chassis fan

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

The following images indicate the location of the rear-chassis fan and provide a visual representation of the removal procedure.



Figure 32. Removing the rear-chassis fan

Steps

- 1. Place the computer on its side with the left side facing up.
- 2. Disconnect the rear-chassis fan cable from its connector (FAN SYS1) on the system board.
- 3. Remove the screw (M3x5) that secures the rear-chassis fan to the chassis.
- 4. Slide and lift the rear-chassis fan off the chassis.

Installing the rear-chassis fan

Prerequisites

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following images indicate the location of the rear-chassis fan and provide a visual representation of the installation procedure.










Figure 33. Installing the rear-chassis fan

- 1. Place the computer on its side with the left side facing up.
- 2. Align the rear-chassis fan with the slot on the chassis.
- 3. Replace the screw (M3x5) that secures the rear-chassis fan to the chassis.
- **4.** Connect the rear-chassis fan cable to its connector (FAN SYS1) on the system board.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Front-chassis fan

Removing the front-chassis fan

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

The following image(s) indicate the location of the front-chassis fan and provides a visual representation of the removal procedure.










Figure 34. Removing the chassis fan

- 1. Place the computer on its side with the left side facing up.
- 2. Slide the release latch to its unlock position and lift the graphics-card end holder away from the front-chassis fan.
 - i NOTE: Skip this step if your graphics card does not ship with a graphics-card end holder.
- 3. Remove the screw (M3x5) that secures the front-chassis fan to the chassis.
- 4. Disconnect the front-chassis fan cable from its connector (FAN SYS2) on the system board.
- **5.** Press down on the securing tab to release the front-chassis fan from the chassis.
- 6. Lift the front-chassis fan off the chassis.

Installing the front-chassis fan


Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the front-chassis fan and provides a visual representation of the installation procedure.










Figure 35. Installing the chassis fan

- 1. Slide the tabs on the front-chassis fan into the slots on the chassis and rotate the rear-chassis fan inwards.
- 2. Press the front-chassis fan against the chassis to snap the chassis fan into place.
- 3. Connect the front-chassis fan cable to its connector (FAN SYS2) on the system board.
- 4. Replace the screw (M3x5) that secures the front-chassis fan to the chassis.
- 5. Align and place the graphics-card end holder on the chassis and slide the latch to its lock position.
 - i NOTE: Skip this step if your computer does not ship with a graphics-card end holder.
- 6. Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Solid state drive (SSD)

Removing the M.2 2230 solid-state drive

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

NOTE: Depending on the configuration ordered, your computer may have up to two M.2 2230 or 2280 solid-state drives installed in the two M.2 solid-state drive slots on the system board (M.2 PCle SSD 0 and M.2 PCle SSD 1).

The following image(s) indicate the location of the M.2 2230 solid-state drive and provides a visual representation of the removal procedure.




Figure 36. Removing the M.2 2230 solid-state drive

Steps

- 1. Place the computer on its side with the left side facing up.
- 2. Remove the screw (M2x3) that secures the M.2 2230 solid-state drive to the system board.
- 3. Slide and lift the M.2 2230 solid-state drive from the M.2 card slot on the system board.

Installing the M.2 2230 solid-state drive

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

NOTE: You may install up to two M.2 2230 or 2280 solid-state drives into the two M.2 solid-state drive slots on the system board (M.2 PCle SSD 0 and M.2 PCle SSD 1).

The following image(s) indicate the location of the M.2 2230 solid-state drive and provides a visual representation of the installation procedure.




Figure 37. Installing the M.2 2230 solid-state drive

- 1. Align the notch on the M.2 2230 solid-state drive with the tab on the M.2 card slot on the system board.
- 2. Slide the M.2 2230 solid-state drive into the M.2 card slot on the system board.
- 3. Replace the screw (M2x3) that secures the M.2 2230 solid-state drive to the system board.
- **4.** Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Removing the M.2 2280 solid-state drive

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

NOTE: Depending on the configuration ordered, your computer may have up to two M.2 2230 or 2280 solid-state drives installed in the two M.2 solid-state drive slots on the system board (M.2 PCle SSD 0 and M.2 PCle SSD 1).

The following image(s) indicate the location of the M.2 2280 solid-state drive and provides a visual representation of the removal procedure.




Figure 38. Removing the M.2 2280 solid-state drive

- 1. Place the computer on its side with the left side facing up.
- 2. Remove the screw (M2x3) that secures the M.2 2280 solid-state drive to the system board.
- 3. Slide and lift the M.2 2280 solid-state drive from the M.2 card slot on the system board.

Installing the M.2 2280 solid-state drive

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

NOTE: You may install up to two M.2 2230 or 2280 solid-state drives into the two M.2 solid-state drive slots on the system board (M.2 PCle SSD 0 and M.2 PCle SSD 1).

The following image(s) indicate the location of the M.2 2280 solid-state drive and provides a visual representation of the installation procedure.




Figure 39. Installing the M.2 2280 solid-state drive

- 1. Align the notch on the M.2 2280 solid-state drive with the tab on the M.2 card slot on the system board.
- 2. Slide the M.2 2280 solid-state drive into the M.2 card slot on the system board.
- 3. Replace the screw (M2x3) that secures the M.2 2280 solid-state drive to the system board.
- **4.** Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Wireless card

Removing the wireless card

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

The following image(s) indicate the location of the wireless card and provides a visual representation of the removal procedure.




Figure 40. Removing the wireless card

- 1. Place the computer on its side with the left side facing up.
- 2. Remove the screw (M2x3.5) that secures the wireless card to the system board.
- 3. Slide and lift the wireless-card bracket off the wireless card.
- **4.** Disconnect the antenna cables from the wireless card.
- 5. Slide and remove the wireless card at an angle from the wireless-card slot (NGFF4).

Installing the wireless card

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the wireless card and provides a visual representation of the installation procedure.




Figure 41. Installing the wireless card

1. Connect the antenna cables to the wireless card.

Table 19. Antenna-cable color scheme

Connector on the wireless card	Antenna-cable color	Silkscreen marking	
Main	White	MAIN	△ (white triangle)
Auxiliary	Black	AUX	▲ (black triangle)

- 2. Slide and place the wireless-card bracket on the wireless card.
- 3. Align the notch on the wireless card with the tab on the wireless-card slot.
- 4. Slide the wireless card at an angle into the wireless-card slot (NGFF4).
- **5.** Replace the screw (M2x3.5) that secures the wireless card to the system board.
- **6.** Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Removing and installing Field Replaceable Units (FRUs)

The replaceable components in this chapter are Field Replaceable Units (FRUs).

- CAUTION: The information in this removing and installing FRUs section is intended for authorized service technicians only.
- CAUTION: To avoid any potential damage to the component or loss of data, ensure that an authorized service technician replaces the Field Replaceable Units (FRUs).
- CAUTION: Dell Technologies recommends that this set of repairs, if needed, to be conducted by trained technical repair specialists.
- CAUTION: As a reminder, your warranty does not cover damages that may occur during FRU repairs that are not authorized by Dell Technologies.
- (i) NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Power-supply unit

Removing the power-supply unit

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

The following images indicate the location of the power-supply unit and provide a visual representation of the removal procedure.




Figure 42. Removing the power-supply unit

- 1. Place the computer on its side with the left side facing up.
- 2. Press down on the securing clip to disconnect the graphics-card power cables from the graphics card.
- 3. Disconnect the graphics-card power cables from the power-supply unit.
- 4. Press the release clips and disconnect the power-supply unit cables from the power-supply unit extension cables.
- 5. Remove the power-supply cables from the routing guides on the chassis.
- **6.** Slide and hold the locking mechanism on the graphics card support bracket, then pull it off the retaining rails on the power-supply cage.
 - NOTE: The size and location of the graphic-card middle holder may vary depending on the graphics card configuration on your computer.
- 7. Remove the two screws (#6-32) that secure the power-supply cage to the chassis.
- 8. Slide and lift the power-supply cage off the chassis.
- 9. Remove the four screws (#6-32) that secure the power-supply unit to the chassis.
 - i NOTE: The number of screws in the power-supply unit depends on the configuration ordered.
- 10. Slide and lift the power-supply unit off the chassis.

Installing the power-supply unit

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following images indicate the location of the power-supply unit and provide a visual representation of the installation procedure.




Figure 43. Installing the power-supply unit

Steps

- 1. Place and align the screw holes on the power-supply unit to the screw holes on the chassis.
- 2. Replace the four screws (#6-32) that secure the power-supply unit to the chassis.
 - NOTE: The number of screws in the power-supply unit depends on the configuration ordered.
- 3. Place and align the screw holes on the power-supply cage to the screw holes on the chassis.
- **4.** Replace the two screws (#6-32) that secure the power-supply cage to the chassis.
- **5.** Insert the graphics-card support bracket onto the retaining rails.

- NOTE: The size and location of the graphic-card middle holder may vary depending on the graphics card configuration on your computer.
- 6. Push the graphics-card supporting bracket down until it locks into position.
- 7. Connect the system-board power cable to the system board.
- 8. Connect the power-supply cables to the processor-power cables.
- 9. Route the power-supply cables through the routing guides on the chassis.
- 10. Connect the graphics-card power cables to the power-supply unit.
- 11. Connect the graphics-card power cables to the graphics card.
- 12. Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Processor fan and heat-sink assembly

Removing the processor fan and heat-sink assembly (65 W, air cooling)

Prerequisites


- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.


About this task

- CAUTION: The heat sink may become hot during normal operation. Allow sufficient time for the heat sink to cool before you touch it.
- NOTE: For maximum cooling of the processor, do not touch the heat-transfer areas on the heat sink. The oils in your skin can reduce the heat-transfer capability of the thermal grease.
- NOTE: This procedure only applies for computers that are shipped with a 65 W processor.

The following images indicate the location of the processor fan and heat-sink assembly (65 W, air cooling) and provide a visual representation of the removal procedure.







- 1. Place the computer on its side with the left side facing up.
- 2. In sequential order (1>2>3>4), loosen the four captive screws that secure the processor fan and heat-sink assembly to the system board.
- 3. Disconnect the processor-fan cable from its connector (FAN CPU) on the system board.
- 4. Lift the processor fan and heat-sink assembly from the system board.

Installing the processor fan and heat-sink assembly (65 W, air cooling)

Prerequisites


If you are replacing a component, remove the existing component before performing the installation process.


About this task

- NOTE: If the processor or the fan and heat-sink assembly is replaced, use the thermal grease that is provided in the kit to ensure that thermal conductivity is achieved.
- i NOTE: This procedure only applies for computers that are shipped with a 65 W processor.

The following images indicate the location of the processor fan and heat-sink assembly (65 W, air cooling) and provide a visual representation of the installation procedure.







- 1. Place the processor fan and heat-sink assembly on the system board and align the captive screws to the screw holes on the system board.
- 2. In reverse sequential order (4>3>2>1), tighten the four captive screws that secure the processor fan and heat-sink assembly to the system board.
- 3. Connect the processor-fan cable to its connector (FAN CPU) on the system board.
- **4.** Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Removing the processor fan and heat-sink assembly (125 W, air cooling)

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.

About this task

CAUTION: The heat sink may become hot during normal operation. Allow sufficient time for the heat sink to cool before you touch it.

- NOTE: For maximum cooling of the processor, do not touch the heat-transfer areas on the heat sink. The oils in your skin can reduce the heat-transfer capability of the thermal grease.
- (i) NOTE: This procedure only applies for computers that are shipped with a 125 W processor.

The following images indicate the location of the processor fan and heat-sink assembly (125 W, air-cooling) and provide a visual representation of the removal procedure.








Figure 44. Removing the processor fan and heat-sink assembly (125 W, air cooling)

- 1. Place the computer on its side with the left side facing up.
- 2. Disconnect the processor fan and heat-sink assembly fan cable from its connector (FAN CPU) on the system board.
- 3. In sequential order(1>2>3>4), loosen the four captive screws that secure the processor fan and heat-sink assembly to the system board.
- **4.** Lift the processor fan and heat-sink assembly from the system board.

Installing the processor fan and heat-sink assembly (125 W, air cooling)

Prerequisites


If you are replacing a component, remove the existing component before performing the installation process.

About this task

- NOTE: If either the processor or the fan and heat-sink assembly is replaced, use the thermal grease that is provided in the kit to ensure that thermal conductivity is achieved.
- i NOTE: This procedure only applies for computers that are shipped with a 125 W processor.

The following images indicate the location of the processor fan and heat-sink assembly (125 W, air cooling) and provide a visual representation of the installation procedure.










Figure 45. Installing the processor fan and heat-sink assembly (125 W, air cooling)

- 1. Place the heat sink on the system board and align the captive screws to the screw holes on the system board.
- 2. In reverse sequential order (4>3>2>1), tighten the four captive screws that secure the processor fan and heat-sink assembly to the system board.
- 3. Connect the processor fan and heat-sink assembly fan cable to its connector (FAN CPU) on the system board.
- 4. Place the computer in an upright position.

Next steps

- 1. Install the left-side cover.
- 2. Follow the procedure in After working inside your computer.

Processor

Removing the processor

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.
- **3.** Remove the fan and heat-sink assembly (65 W) or the fan and heat-sink assembly (125 W, air cooling), whichever is applicable.

About this task

The following images indicate the location of the processor and provide a visual representation of the removal procedure.




Figure 46. Removing the processor

- 1. Press the release lever down and then push it away from the processor to release it from the securing tab.
- 2. Extend the release lever completely and open the processor cover.

CAUTION: When removing the processor, do not touch any of the pins inside the socket or allow any objects to fall on the pins in the socket.

3. Gently lift the processor from the processor socket.

Installing the processor

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following images indicate the location of the processor and provide a visual representation of the installation procedure.




Figure 47. Installing the processor

- 1. Ensure that the release lever on the processor socket is fully extended in the open position.
 - NOTE: The pin-1 corner of the processor has a triangle that aligns with the triangle on the pin-1 corner on the processor socket. When the processor is properly seated, all four corners are aligned at the same height. If one or more corners of the processor are higher than the others, the processor is not seated properly.
- 2. Align the notches on the processor with the tabs on the processor socket and place the processor in the processor socket.
 - CAUTION: Ensure that the processor-cover notch is positioned underneath the alignment post.
- When the processor is fully seated in the socket, pivot the release-lever down and place it under the tab on the processor cover.

Next steps

- 1. Install the fan and heat-sink assembly (65 W) or the fan and heat-sink assembly (125 W, air cooling), whichever is applicable.
- 2. Install the left-side cover.
- **3.** Follow the procedure in After working inside your computer.

Voltage-regulator heat sink

Removing the voltage-regulator heat sink

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.
- **3.** Remove the processor fan and heat-sink assembly (65 W, air cooling) or the processor fan and heat-sink assembly (125 W, air cooling), whichever is applicable.

About this task

NOTE: The heat sink may become hot during normal operation. Allow sufficient time for the heat sink to cool before you touch it.

NOTE: For maximum cooling of the processor, do not touch the heat-transfer areas on the heat sink. The oils in your skin can reduce the heat-transfer capability of the thermal grease.

The following images indicate the location of the voltage-regulator heat sink and provide a visual representation of the removal procedure.








Figure 48. Removing the voltage-regulator heat sink

Steps

- 1. Place the computer on its side with the left side facing up.
- 2. Remove the four captive screws that secure the voltage-regulator heat sink to the system board.
- 3. Lift the voltage-regulator heat sink off the system board.

Installing the voltage-regulator heat sink

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following images indicate the location of the voltage-regulator heat sink and provide a visual representation of the installation procedure.








Figure 49. Installing the voltage-regulator heat sink

Steps

- 1. Place the voltage-regulator heat sink on the system board.
- 2. Align the captive screws on the voltage-regulator heat sink to the screw holes on the system board.
- 3. Tighten the four captive screws that secure the voltage-regulator heat stink to the system board.
- **4.** Place the computer in an upright position.

Next steps

- 1. Install the processor fan and heat-sink assembly (65 W, air cooling) or the processor fan and heat-sink assembly (125 W, air cooling), whichever is applicable.
- 2. Install the left-side cover.
- 3. Follow the procedure in After working inside your computer.

System board

Removing the system board

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the left-side cover.
- 3. Remove the front cover.
- **4.** Remove the memory modules.
- 5. Remove the M.2 2230 solid-state drive or the M.2 2280 solid-state drive, whichever is applicable.
- 6. Remove the graphics card, if applicable.
- 7. Remove the wireless card.
- 8. Remove the coin-cell battery.
- 9. Remove the fan and heat-sink assembly (65 W) or the fan and heat-sink assembly (125 W, air cooling), whichever is applicable.
- **10.** Remove the processor.
- 11. Remove the voltage-regulator heat sink, if applicable.

About this task

The following image indicates the slots and connectors on your system board.




Figure 50. System-board connectors

- 1. Processor-power connectors (ATX CPU2 and ATX CPU1)
- 2. CPU socket (CPU)
- **3.** Memory-module slots (DIMM1 and DIMM2)
- **4.** SATA-power connector (SATA PWR)
- 5. M.2 2230 or M.2 2280 solid-state drive slot (M.2 PCle SSD 1)
- 6. Coin-cell battery socket (RTC)
- 7. M.2 2230 wireless-card slot (M.2 WLAN)
- **8.** Power-button connector (PWR SW)
- 9. Front-chassis fan connector (FAN SYS2)
- 10. M.2 2230 or M.2 2280 solid-state drive slot (M.2 PCle SSD 0)
- 11. SATA 6 Gbps drive connector (SATA-0)
- 12. SATA 6 Gbps drive connector (SATA-1)
- **13.** SATA 6 Gbps drive connector (SATA-2)
- 14. Power-supply connector (ATX SYS)
- 15. PCle x4 slot (SLOT 3)
- 16. PCle x4 slot (SLOT 2)
- 17. PCle x16 slot (SLOT 1)
- 18. Rear chassis-fan cable connector (FAN SYS1)
- 19. Processor-fan cable connector (FAN CPU)

The following images indicate the location of the system board and provide a visual representation of the removal procedure.




Figure 51. Removing the system board



Figure 52. Removing the system board




Figure 53. Removing the system board



Figure 54. Removing the system board

Steps

- 1. Remove the screw (#6-32) that secures the front I/O-bracket to the chassis.
- 2. Rotate and remove the front I/O-bracket from the chassis.
- 3. Disconnect the power-supply cable from its connector (ATX SYS) on the system board.
 - NOTE: Note the routing of all cables as you remove them so that you can route them correctly after you replace the system board. For information about system-board connectors, see "System-board connectors".
 - NOTE: Note the routing of all cables as you remove them so that you can route them correctly after you replace the system board.
- 4. Press the release clips and disconnect the power-supply unit cables from the power-supply unit extension cables.
- Disconnect the SATA drive cable from its connector (SATA-0) on the system board.Repeat this step to disconnect the rest of SATA drive cables from their connectors (SATA-1 and SATA-2), if applicable.
- 6. Disconnect the power-button cable from its connector (PWR SW) on the system board.
- 7. Disconnect the SATA power cable from its connector (SATA PWR) on the system board.
- 8. Disconnect the processor-power cables from their connectors on the system board (ATX CPU1 and ATX CPU2).
- 9. Release the power-supply unit extension cables from their black plastic clips and lift the section of the cables away from the system board.
- 10. Remove the nine screws (#6-32) that secure the system board to the chassis.
- 11. Lift the system board at an angle and remove it from the chassis.

Installing the system board

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image indicates the slots and connectors on your system board.




Figure 55. System board connectors

1. Processor-power connectors (ATX CPU2 and ATX CPU1)

- 2. CPU socket (CPU)
- **3.** Memory-module slots (DIMM1 and DIMM2)
- **4.** SATA-power connector (SATA PWR)
- 5. M.2 2230 or M.2 2280 solid-state drive slot (M.2 PCle SSD 1)
- 6. Coin-cell battery socket (RTC)
- 7. M.2 2230 wireless-card slot (M.2 WLAN)
- 8. Power-button connector (PWR SW)
- 9. Front-chassis fan connector (FAN SYS2)
- 10. M.2 2230 or M.2 2280 solid-state drive slot (M.2 PCle SSD 0)
- 11. SATA 6 Gbps drive connector (SATA-0)
- 12. SATA 6 Gbps drive connector (SATA-1)
- 13. SATA 6 Gbps drive connector (SATA-2)
- 14. Power-supply connector (ATX SYS)
- 15. PCle x4 slot (SLOT 3)
- 16. PCle x4 slot (SLOT 2)
- 17. PCle x16 slot (SLOT 1)
- 18. Rear chassis-fan cable connector (FAN SYS1)
- 19. Processor-fan cable connector (FAN CPU)

The following images indicate the location of the system board and provide a visual representation of the installation procedure.







Figure 56. Installing the system board




Figure 57. Installing the system board



Figure 58. Installing the system board



Figure 59. Installing the system board

Steps

- 1. Slide the back I/O-ports on the system board into the front I/O-slots on the chassis. Align the screw holes on the system board with the screw holes on the chassis.
- 2. Replace the nine screws (#6-32) that secure the system board to the chassis.
- 3. Place the section of the the power-supply unit extension cables over the system board and secure the cables with their black plastic clips.
- 4. Connect the processor-power cables to their connectors on the system board (ATX CPU1 and ATX CPU2).
- 5. Connect the SATA power cable to its connector (SATA PWR) on the system board.
- **6.** Connect the power-button cable to its connector (PWR SW) on the system board.
- 7. Connect the SATA drive cable to its connector (SATA-0) on the system board.

Repeat this step to connect the rest of SATA drive cables to their connectors (SATA-1 and SATA-2), if applicable.

- **8.** Connect the power-supply unit cables to the power-supply unit extension cables.
- 9. Connect the power-supply cable to its connector (ATX SYS) on the system board.
- 10. Place and align the front I/O-bracket with the I/O slot on the chassis.
- 11. Replace the screw (#6-32) that secures the front I/O-bracket to the chassis.

Next steps

- 1. Install the voltage-regulator heat sink, if applicable.
- 2. Install the processor.
- 3. Install the fan and heat-sink assembly (65 W) or the fan and heat-sink assembly (125 W, air cooling), whichever is applicable.
- **4.** Install the coin-cell battery.
- 5. Install the wireless card.
- 6. Install the graphics card, if applicable.
- 7. Install the M .2 2230 solid-state drive or the M .2 2280 solid-state drive, whichever is applicable.
- 8. Install the memory modules.
- 9. Install the front cover.
- 10. Install the left-side cover.
- 11. Follow the procedure in After working inside your computer.

Software

This chapter details the supported operating systems along with instructions on how to install the drivers.

Operating system

Your Dell Tower EBT2250 supports the following operating systems:

- Windows 11 Pro, 64-bit
- Windows 11 Home, 64-bit

Drivers and downloads

When troubleshooting, downloading, or installing drivers, it is recommended that you read the Dell Knowledge Base article Drivers and Downloads FAQs 000123347.

BIOS Setup

NOTE: Depending on the computer and the installed devices, the options that are listed in this section may or may not be displayed.

CAUTION: Certain changes can make your computer work incorrectly. Before you change the settings in BIOS Setup, it is recommended that you note down the original settings for future reference.

Use BIOS Setup for the following purposes:

- Get information about the hardware installed in your computer, such as the amount of RAM and the capacity of the storage device.
- Change the system configuration information.
- Set or change a user-selectable option, such as the user password, type of storage device installed, and enable or disable base devices

Entering BIOS Setup program

About this task

Turn on (or restart) your computer and press F2 immediately.

Navigation keys

NOTE: For most of the BIOS Setup options, changes that you make are recorded but do not take effect until you restart the computer.

Table 20. Navigation keys

Keys	Navigation
Up arrow	Moves to the previous field.
Down arrow	Moves to the next field.
Enter	Selects a value in the selected field (if applicable) or follows the link in the field.
Spacebar	Expands or collapses a drop-down list, if applicable.
Tab	Moves to the next focus area.
Esc	Moves to the previous page until you view the main screen. Pressing Esc in the main screen displays a message that prompts you to save any unsaved changes and restart the computer.

One time boot menu

To access the **one time boot menu**, turn on your computer, and then press F2 immediately.

(i) NOTE: If your computer fails to enter the boot menu, restart the computer and press F2 immediately.

The one-time boot menu displays the devices that you can boot from, and also displays the option to start diagnostics. The boot menu options are:

• Removable Drive (if available)

- STXXXX Drive (if available)
 - i NOTE: XXX denotes the SATA drive number.
- Optical Drive (if available)
- SATA Hard Drive (if available)
- Diagnostics
 - i NOTE: Choosing Diagnostics, will display the ePSA diagnostics screen.

The one time boot menu also displays the option to access the System Setup screen.

F12 One Time Boot menu

To enter the One Time Boot menu, turn on or restart your computer, and then press F12 immediately.

NOTE: If you are unable to enter the One Time Boot menu, repeat the above action.

The One Time Boot menu displays the devices that you can boot from and also display the options to start diagnostics. The boot menu options are:

- Removable Drive (if available)
- STXXXX Drive (if available)
 - i NOTE: XXX denotes the SATA drive number.
- Optical Drive (if available)
- SATA Hard Drive (if available)
- Diagnostics

The One Time Boot menu screen also displays the option to access BIOS Setup.

System setup options

(i) NOTE: Depending on your computer and its installed devices, the items listed in this section may or may not appear.

Table 21. System setup options—Overview

Overview	
Dell Tower EBT2250	
BIOS Version	Displays the BIOS version number.
Service Tag	Displays the Service Tag of the computer.
Asset Tag	Displays the Asset Tag of the computer.
Manufacture Date	Displays the manufacture date of the computer.
Ownership Date	Displays the ownership date of the computer.
Express Service Code	Displays the express service code of the computer.
Ownership Tag	Displays the Ownership Tag of the computer.
Signed Firmware Update	Displays whether the Signed Firmware Update is enabled on your computer.
	By default, the Signed Firmware Update option is enabled.
PROCESSOR	
Processor Type	Displays the processor type.
Maximum Clock Speed	Displays the maximum processor clock speed.
Minimum Clock Speed	Displays the minimum processor clock speed.

Table 21. System setup options—Overview (continued)

Overview

Current Clock Speed Displays the current processor clock speed.

Core Count Displays the number of cores on the processor.

Processor ID Displays the processor identification code.

Processor L2 Cache Displays the processor L2 Cache size.

Processor L3 Cache Displays the processor L3 Cache size.

Microcode Version Displays the microcode version.

Intel® Hyper-Threading Capable Displays whether the processor is Hyper-Threading (HT) capable.

64-Bit Technology Displays whether 64-bit technology is used.

Intel vPro Technology® Display whether the Intel vPro feature is supported.

MEMORY

Memory Installed Displays the total computer memory installed.

Memory Available Displays the total computer memory available.

Memory Speed Displays the memory speed.

Memory Channel Mode Displays single or dual channel mode.

Memory Technology Displays the technology that is used for the memory.

DIMM 1 Size Displays the DIMM 1 memory size.

DIMM 2 Size Displays the DIMM 2 memory size.

DEVICES

Video Controller Displays the video controller type of the computer.

Video Memory Displays the video memory information of the computer.

Wi-Fi Device Displays the wireless device information of the computer.

Native Resolution Displays the native resolution of the computer.

Video BIOS Version Displays the video BIOS version of the computer.

Audio Controller Displays the audio controller information of the computer.

Bluetooth® Device Displays the Bluetooth device information of the computer.

LOM MAC Address Displays the LAN On Motherboard (LOM) MAC address of the computer.

Slot 1 Displays the graphics or expansion card that is installed in Slot 1.

Slot 2 Displays the expansion card that is installed in Slot 2.
Slot 3 Displays the expansion card that is installed in Slot 3.

Table 22. System setup options—Boot Configuration menu

Boot Configuration

Boot Sequence

Boot Sequence

Boot Mode: UEFI only Displays the boot mode.

Enable PXE Boot Priority Enables or disables the option to add a new PXE boot to the top of the Boot

Displays the boot sequence.

Sequence.

By default, the **OFF** option is disabled.

Force PXE On Next Boot Enables or disables the Force PXE feature on the next boot.

By default, the ${\bf Force}\ {\bf PXE}\ {\bf On}\ {\bf Next}\ {\bf Boot}$ option is disabled.

Table 22. System setup options—Boot Configuration menu (continued)

oot Configuration	
Secure Boot	
Enable Secure Boot	Enable or disable the secure boot feature.
	By default, the OFF option is disabled.
Enable Microsoft UEFI CA	Enable or disable Microsoft UEFI Certificate Authority.
	By default, the ON option is enabled.
	CAUTION: Disabling Microsoft UEFI CA could render your system being unable to boot. System graphics may not function, some devices may not function properly. The system could become unrecoverable.
Secure Boot Mode	Change the secure boot mode options.
	By default, the Deployed Mode option is enabled.
Expert Key Management	
Enable Custom Mode	Enable or disable custom mode.
	By default, the OFF option is disabled.
Custom Mode Key Management	Select the custom values for expert key management.

Table 23. System setup options—Integrated Devices menu

Integrated Devices	
Date/Time	Set the current date in MM/DD/YYYY format.
Time	Set the current time in HH:MM:SS AM/PM format.
Enable Audio	Enable or disable the integrated audio controller.
	By default, all the options are enabled.
USB/Thunderbolt Configuration	
Enable Thunderbolt™ Support	Enable or disable the Thunderbolt™ Technology feature, ports and adapters.
	By default, the ON option is enabled.
	(i) NOTE: Enabling the "Enable Thunderbolt™ Adapter Boot Support" or "Enable Thunderbolt™ Adapter Pre-boot Modules" options may allow devices connected to the Thunderbolt™ adapter during pre-boot to function in the operating system regardless of the Security Level selected in BIOS Setup.
Enable Thunderbolt™ Boot Support	Enable or disable the Thunderbolt™ Boot support.
	By default, the OFF option is disabled.

Table 24. System setup options—Storage menu

Storage	
SATA/NVMe Operation	Enable or disable the operating mode of the integrated SATA hard drive controller.
	By default, the RAID On option is enabled.
Storage Interface	
Port Enablement	Enable or disable the onboard drives.
	By default, all the onboard drives are enabled.
SATA-0	Enable or disable the SATA-0 drive.

Table 24. System setup options—Storage menu (continued)

SATA-1 Enable or disable the SATA-1 drive.

By default, the **ON** option is enabled.

By default, the **ON** option is enabled.

SATA-2 Enable or disable the SATA-2 drive.

By default, the **ON** option is enabled.

M.2 PCIe SSD-0 Enable or disable the M.2 PCIe SSD-0 solid-state drive.

By default, the **ON** option is enabled.

M.2 PCIe SSD-1 Enable or disable the M.2 PCIe SSD-1 solid-state drive.

By default, the **ON** option is enabled.

SMART Reporting

Enable SMART Reporting Enable or disable Self-Monitoring, Analysis, and Reporting Technology

(SMART) during computer startup.

By default, the **OFF** option is disabled.

Drive Information

SATA-0

Type Displays the SATA-0 type information of the computer.

Dervice Displays the SATA-0 device information of the computer.

SATA-1

Type Displays the SATA-1 type information of the computer.

Dervice Displays the SATA-1 device information of the computer.

SATA-2

Type Displays the SATA-2 type information of the computer.

Dervice Displays the SATA-2 device information of the computer.

M.2 PCIe SSD-0

Type Displays the M.2 PCle SSD-0 type information of the computer.

Device Displays the M.2 PCle SSD-0 device information of the computer.

M.2 PCIe SSD-1

Type Displays the M.2 PCle SSD-1 type information of the computer.

Device Displays the M.2 PCle SSD-1 device information of the computer.

Enable MediaCard

Enable or disable all media cards.

By default, the **Secure Digital (SD)** option is selected.

Table 25. System setup options—Display menu

Display	
Primary Display	Determines the primary display when multiple controllers are available on the computer.
	By default, the Auto option is enabled.
Full Screen Logo	Enable or disable full screen logo.

Table 25. System setup options—Display menu (continued)

Display

By default, the **OFF** option is disabled.

Table 26. System setup options—Connection menu

Connection

Network Controller Configuration

Integrated NIC Controls the on-board LAN controller.

By default, the **Enabled with PXE** option is selected.

Wireless Device Enable

WLAN/WGig Enable or disable the internal WLAN device.

By default, the **WLAN/WGig** option is selected.

Bluetooth® Enable or disable the internal Bluetooth device.

By default, the **Bluetooth®** option is selected.

Enable UEFI Network Stack Enable or disable UEFI Network Stack and controls the on-board LAN

Controller.

By default, the Auto Enabled option is selected.

HTTP(s) Boot Feature

HTTP(s) Boot Enable or disable the HTTP(s) Boot feature.

By default, the **ON** option is enabled.

HTTP(s) Boot Mode With Auto Mode, the HTTP(s) Boot extracts Boot URL from the DHCP. With

Manual Mode, the HTTP(s) Boot reads Boot URL from the user-provided data.

By default, the **Auto Mode** option is selected.

Table 27. System setup options—Power menu

Power

USB PowerShare

Enable USB PowerShare When enabled, USB devices connected to the designated USB PowerShare

port on the computer are powered or charged using the stored system battery.

By default, the **OFF** option is disabled.

Thermal Management Select the heat management settings for the cooling fan and the processor,

with respect to system performance, noise, and temperature.

By default, the ${\bf Optimized}$ option is selected.

USB Wake Support

Enable USB Wake Support When enabled, you can use the USB devices like a mouse or keyboard to wake

your computer from standby.

By default, the $\boldsymbol{\mathsf{ON}}$ option is enabled.

AC Behavior

AC Recovery

Allows you to determine what happens when AC power is restored after an

unexpected loss of AC power.

By default, the ${\bf Power\ Off}$ option is selected.

Block Sleep Enables or disables the computer from entering Sleep (S3) mode in the

operating system.

Table 27. System setup options—Power menu (continued)

Power

By default, the **OFF** option is disabled.

NOTE: When enabled, the computer does not go to Sleep, Intel Rapid Start is disabled automatically, and the operating system power option is blank if it was set to Sleep.

Deep Sleep Control Enable or disable the Deep Sleep mode support.

By default, the **Enabled in S4 and S5** option is selected.

Intel Speed Shift Technology Enable or disable the Intel Speed Shift Technology support.

By default, the **ON** option is enabled.

Table 28. System setup options—Security menu

_				٠.	
•	•	\sim 1	1 1	ıt	.,
J	┏,	_	41	ıL	v

TPM 2.0 Security

TPM 2.0 Security On Enable or disable TPM 2.0 security options.

By default, the \mathbf{ON} option is enabled.

Attestation Enable Enables to control whether the Trusted Platform Module (TPM) Endorsement

Hierarchy is available to the operating system.

By default, the **ON** option is enabled.

Key Storage Enable Enables to control whether the Trusted Platform Module (TPM) Storage

Hierarchy is available to the operating system.

By default, the **ON** option is enabled.

Clear Enables to clear the TPM owner information and returns the TPM to the

default state.

By default, the **OFF** option is enabled.

PPI ByPass for Clear Commands Controls the TPM Physical Presence Interface (PPI).

By default, the **OFF** option is enabled.

SMM Security Mitigation Enables or disables additional UEFI SMM Security Mitigation protections. This

option uses the Windows SMM Security Mitigations Table (WSMT) to confirm to the operating system that security best practices have been implemented

by the UEFI firmware.

By default, the \mathbf{ON} option is enabled.

For additional security, Dell Technologies recommends keeping the **SMM Security Mitigation** option enabled unless you have a specific application

which is not compatible.

(i) **NOTE:** This feature may cause compatibility issues or loss of functionality with some legacy tools and applications.

Data Wipe on Next Boot

Start Data WipeData Wipe is a secure wipe operation that deletes information from a storage device.

WARNING: The secure Data Wipe operation deletes information in a way that it cannot be reconstructed.

Commands such as delete and format in the operating system may remove files from showing up in the file system. However, they can be reconstructed through forensic means as they are still represented on the physical media. Data Wipe prevents this reconstruction and is not recoverable.

Table 28. System setup options—Security menu (continued)

Security

When enabled, the data wipe option will prompt to wipe any storage devices

that are connected to the computer on the next boot.

By default, the **OFF** option is disabled.

HDD Security

SED Block SID Authentication The SEO Block SID Authentication setting controls a mechanism used by the

BIDS to block entities from taking ownership of the Self-Encrypting Drive

(SED) when the drive does not have a password set.

By default, the **ON** option is enabled.

PPI BYpass for SED Block SID

Command

This setting controls the SEO Block SID Physical Presence Interlace (PPI). When external SEO management software sends a request to BIOS to leave the drive in an unlocked state, this setting controls whether the user must

acknowledge and approve the request.

By default, the **OFF** option is disabled.

Absolute®

Passwords

Lower Case Letter

Absolute® Absolute Software provides various cyber security solutions, some requiring

software preloaded on Dell computers and integrated into the BIOS. To use these features, you must enable the Absolute BIOS setting and contact

Absolute for configuration and activation.

By default, the **Enable Absolute** option is enabled.

For additional security, Dell Technologies recommends keeping the **Absolute**

option enabled.

NOTE: When the Absolute features are activated, the Absolute integration

cannot be disabled from the BIOS setup screen.

UEFI Boot Path Security

• UEFI Boot Path Security Enables or disables the computer to prompt the user to enter the

Administrator password (if set) when booting to a UEFI boot path device from

the F12 boot menu.

By default, the Always Except Internal HDD option is selected.

Reinforces password must have at least one lower case letter.

Table 29. System setup options—Passwords menu

 455410145	
Admin Password	Set, change, or delete the administrator password.
System Password	Set, change, or delete the computer password.
M.2 PCIe SSD-0	Set, change, or delete the M.2 PCle SSD-0 password.
M.2 PCIe SSD-1	Set, change, or delete the M.2 PCle SSD-1 password.
Password Configuration	The Password configuration page includes several options for changing the requirements of BIOS passwords. You can modify the minimum and maximum length of the passwords and require passwords to contain certain character classes (upper case, lower case, digit, special character).
	Dell Technologies recommends setting the minimum password length to at least eight characters.
Upper Case Letter	Reinforces password must have at least one upper case letter.
	By default, the OFF option is enabled.

By default, the **OFF** option is enabled.

Table 29. System setup options—Passwords menu (continued)

Digit	Reinforces password must have at least one digit.
	By default, the OFF option is enabled.
Special Character	Reinforces password must have at least one special character.
	By default, the OFF option is enabled.
Minimum Characters	Set the minimum characters allowed for password.
	By default, the Minimum Characters value is set to 4.
Password Bypass	
Password Bypass	When enabled, this always prompts for computer and internal hard drive passwords when powered on from the off state.
	By default, the Disabled option is enabled.
Password Changes	
Allow Non-Admin Password Changes	The Enable Non-Admin Password Changes option in BIOS setup allows an end user to set or change the computer or hard drive passwords without entering the administrator password. This gives an administrator control ove the BIOS settings but enables an end user to provide their own password.
	By default, the ON option is enabled.
	For additional security, Dell Technologies recommends keeping the Enable Non-Admin Password Changes option disabled.
Admin Setup Lockout	
Enable Admin Setup Lockout	The Enable Admin Setup Lockout option prevents an end user from even viewing the BIOS setup configuration without first entering the administrator password (if set).
	By default, the OFF option is disabled.
	For additional security, Dell Technologies recommends keeping the Enable Admin Setup Lockout option disabled.
Master Password Lockout	
Enable Master Password Lockout	The Master Password Lockout setting allows you to disable the Recovery Password feature. If the computer, administrator, or hard drive password is forgotten, the computer becomes unusable. NOTE: When the owner password is set, the Master Password Lockout option is not available.
	(i) NOTE: When an internal hard drive password is set, it must first be clear before Master Password Lockout can be changed.
	By default, the OFF option is disabled.
	Dell does not recommend enabling the Master Password Lockout unless you have implemented your own password recovery computer.
Allow Non-Admin PSID Revert	
Enable Allow Non-Admin PSID Revert	Controls access to the Physical Security ID (PSID) revert of NVMe hard-driv from the Dell Security Manager prompt.
	By default, the OFF option is disabled.

Table 30. System setup options—Update, Recovery menu

Table 50. System setup options—optiate, Necovery menu	
Update, Recovery	
UEFI Capsule Firmware Updates	

Table 30. System setup options—Update, Recovery menu (continued)

Update, Recovery

Enable UEFI Capsule Firmware Updates

Enables or disables BIOS updates through UEFI capsule update packages.

NOTE: Disabling this option blocks the BIOS updates from services such as Microsoft Windows Update and Linux Vendor Firmware Service (LVFS).

By default, the **ON** option is enabled.

BIOS Recovery from Hard Drive

Enables or disables the user to recover from certain corrupted BIOS conditions from a recovery file on the user primary hard drive or an external USB key.

By default, the **ON** option is enabled.

NOTE: BIOS Recovery from Hard Drive is not available for self-encrypting drives (SED).

(i) NOTE: BIOS recovery is designed to fix the main BIOS block and cannot work if the Boot Block is damaged. In addition, this feature cannot work in the event of EC corruption, ME corruption, or a hardware issue. The recovery image must exist on an unencrypted partition on the drive.

BIOS Downgrade

Allow BIOS Downgrade

Controls flashing of the computer firmware to previous revisions.

By default, the **ON** option is enabled.

SupportAssist OS Recovery

SupportAssist OS Recovery

Enables or disables the boot flow for SupportAssist OS Recovery tool in the event of certain computer errors.

By default, the **ON** option is enabled.

BIOSConnect

BIOSConnect

Enables or disables cloud Service operating system recovery if the main operating system fails to boot with the number of failures equal to or greater than the value specified by the Auto operating system Recovery Threshold setup option and local Service operating system does not boot or is not installed.

By default, the **ON** option is enabled.

Dell Auto OS Recovery Threshold

Dell Auto OS Recovery Threshold

Allows you to control the automatic boot flow for SupportAssist System Resolution Console and for Dell operating system Recovery Tool.

By default, the value of 2 option is selected.

Table 31. System setup options—System Management menu

System Management

Service Tag

Service Tag

Asset Tag

Asset Tag

Creates a computer Asset Tag that can be used by an IT administrator to

uniquely identify a particular computer.

i NOTE: Once set in BIOS, the Asset Tag cannot be changed.

Wake on LAN/WLAN

Wake on LAN/WLAN Enables or disables the computer to turn on by special LAN signals.

By default, the **Disabled** option is selected.

Auto On Time

Table 31. System setup options—System Management menu (continued)

System Management **Auto On Time** Enable to set the computer to turn on automatically every day or on a preselected date and time. This option can be configured only if the Auto On Time is set to Everyday, Weekdays, or Selected Days. By default, the **Disabled** option is selected. **SERR Messages Enable SERR Messages** Enable or disable SERR (system error) messages. By default, the **ON** option is enabled. First Power On Date Set Ownership Date Set the ownership date. By default, the **OFF** option is enabled. **Diagnostics OS Agent Requests** Enables OS agent request to schedule onboard diagnostics. By default, the **ON** option is enabled. Power-On-Self-Test Automatic Recovery Power-On-Self-Test Automatic Enables automatic recovery when the computer becomes unresponsive when Recovery performing a BIOS Power-On-Self-Test (POST). If the computer becomes unresponsive before POST is completed, the BIOS will automatically attempt to recover the computer. In some cases, this may include resetting the BIOS Setup configuration settings to BIOS default values, and unprovisioning the Intel AMT vPro feature, if applicable.

Table 32. System setup options—Keyboard menu

eyboard	
Keyboard Errors	
Enable Keyboard Error Detectio	Enable or disable the keyboard error detection feature.
	By default, the ON option is enabled.
Numlock LED	
Enable Numlock LED	Enable or disable Numlock LED.
	By default, the ON option is enabled.

By default, the \mathbf{ON} option is enabled.

Pre-boot Behavior	
Warning and Errors	
Warning and Errors	Enables or disables the action to be taken when a warning or error is encountered.
	By default, the Prompt on Warnings and Errors option is selected. Stop, prompt, and wait for user input when warnings or errors are detected. (i) NOTE: Errors deemed critical to the operation of the computer hardware stop the functioning of the computer.
Extend BIOS POST Time	
Extend BIOS POST Time	Sets the BIOS POST (Power-On Self-Test) load time.

Table 33. System setup options—Pre-boot Behavior menu (continued)

Pre-boot Behavior	
	By default, the 0 seconds option is selected.

Table 34. System setup options—Virtualization menu

rtualization	
Intel® Virtualization Technology	
Enable Intel® Virtualization Technology (VT)	When enabled, the computer can run a Virtual Machine Monitor (VMM).
	By default, the ON option is enabled.
VT for Direct I/O	
Enable Intel® VT for Direct I/O	When enabled, the computer can perform Virtualization Technology for Direct I/O (VT-d). VT-d is an Intel method that provides virtualization for memory map I/O.
	By default, the ON option is enabled.
Intel® Trusted Execution Technology (TXT)	Intel Trusted Execution Technology (TXT) is a set of hardware extensions to Intel processors and chipsets. It provides a hardware-based root of trust to ensure that a platform boots with a known good configuration of firmware, BIOS, virtual machine monitor, and operating system. The following must be enabled in order to enable Intel TXT - • Intel Virtualization Technology - X • Intel Virtualization Technology - Direct
DMA Protection	
Enable Pre-Boot DMA support.	Allows you to control the Pre-Boot DMA protection for both internal and external ports. This option does not directly enable DMA protection in the operating system. (i) NOTE: This option is not available when the virtualization setting for IOMMU is disabled (VT-d/AMD Vi).
	By default, the ON option is enabled.
	For additional security, Dell Technologies recommends keeping the Enable Pre-Boot DMA Support option enabled.
	NOTE: This option is provided only for compatibility purposes, since some older hardware is not DMA capable.
Enable OS Kernel DMA support	Allows you to control the Kernel DMA protection for both internal and external ports. This option does not directly enable DMA protection in the operating system. For operating systems that support DMA protection, this setting indicates to the operating system that the BIOS supports the feature. (i) NOTE: This option is not available when the virtualization setting for IOMMU is disabled (VT-d/AMD Vi).
	By default, the ON option is enabled. (i) NOTE: This option is provided only for compatibility purposes, since some older hardware is not DMA capable.
Internal Port DMA Compatability Mode	When enabled, BIOS will notify the OS that the internal ports are not OMA capable.
	This is intended to help with devices that have OS OMA compatibility issues. This setting does not affect external port OMA or Pre-boot OMA support.
	By default, the OFF option is disabled.

Table 35. System setup options—Performance menu

rformance	
Multi-Core Support	
Active Multiple Performance Cores (P-Cores) Select	Change the number of CPU cores available to the operating system. The default value is set to the maximum number of cores.
	By default, the All Active option is selected.
Active Multiple Efficient Cores (P-Cores) Select	Change the number of CPU E-cores available to the operating system. The default value is set to the maximum number of cores.
	By default, the All Active option is selected.
Intel® SpeedStep	
Enable Intel® SpeedStep Technology	Enables the computer to dynamically adjust processor voltage and core frequency, decreasing average power consumption and heat production.
	By default, the ON option is enabled.
C-States Control	
Enable C-State Control	Enables or disables the ability of the CPU to enter and exit low-power state When disabled, it disables all C-states. When enabled, it enables all C-states that the chipset or platform allows.
	By default, the ON option is enabled.
Intel® Turbo Boost Technology	
Enable Intel® Turbo Boost Technology	Enables the Intel® TurboBoost™ mode of the processor. When enabled, the Intel TurboBoost driver increases the performance of the CPU or graphics processor.
	By default, the ON option is enabled.
Intel® Hyper-Threading Technology	
PCIe Resizable Base Address Register (BAR)	
Enable PCIe Resizable Base Address	Enable or disable PCIe Resizable BAR support.

Table 36. System setup options—System Logs menu

stem Logs	
BIOS Event Log	
Clear Bios Event Log	Allows you to select option to keep or clear BIOS events logs.
	By default, the Keep Log option is selected.
Power Event Log	
Clear Power Event Log	Allows you to select option to keep or clear Power events logs.
	By default, the Keep Log option is selected.

By default, the **OFF** option is disabled.

Updating the BIOS

Register (BAR) support

Updating the BIOS in Windows

Steps

1. Go to Dell Support Site.

- 2. Go to **Identify your product or search support**. In the box, enter the product identifier, model, service request or describe what you are looking for, and then click **Search**.
 - NOTE: If you do not have the Service Tag, use the SupportAssist to automatically identify your computer. You can also use the product ID or manually browse for your computer model.
- 3. Click Drivers & Downloads. Expand Find drivers.
- 4. Select the operating system installed on your computer.
- 5. In the Category drop-down list, select BIOS.
- 6. Select the latest version of BIOS, and click **Download** to download the BIOS file for your computer.
- 7. After the download is complete, browse the folder where you saved the BIOS update file.
- 8. Double-click the BIOS update file icon and follow the on-screen instructions.

 For more information about how to update the system BIOS, search in the Knowledge Base Resource at Dell Support Site.

Updating the BIOS using the USB drive in Windows

Steps

- 1. Go to Dell Support Site.
- 2. Go to **Identify your product or search support**. In the box, enter the product identifier, model, service request or describe what you are looking for, and then click **Search**.
 - NOTE: If you do not have the Service Tag, use the SupportAssist to automatically identify your computer. You can also use the product ID or manually browse for your computer model.
- 3. Click Drivers & Downloads. Expand Find drivers.
- 4. Select the operating system installed on your computer.
- 5. In the **Category** drop-down list, select **BIOS**.
- 6. Select the latest version of BIOS, and click **Download** to download the BIOS file for your computer.
- 7. Create a bootable USB drive. For more information, search the Knowledge Base Resource at Dell Support Site.
- 8. Copy the BIOS Setup program file to the bootable USB drive.
- 9. Connect the bootable USB drive to the computer that needs the BIOS update.
- 10. Restart the computer and press F12 .
- 11. Select the USB drive from the One Time Boot Menu.
- **12.** Type the BIOS Setup program filename and press **Enter**. The **BIOS Update Utility** appears.
- 13. Follow the on-screen instructions to complete the BIOS update.

Updating the BIOS from the One-Time boot menu

You can run the BIOS flash update file from Windows using a bootable USB drive or you can also update the BIOS from the One-Time boot menu on the computer. To update your computers BIOS, copy the BIOS XXXX.exe file onto a USB drive formatted with the FAT32 file system. Then, restart your computer and boot from the USB drive using the One-Time Boot Menu.

About this task

BIOS Update

To confirm if the BIOS Flash Update is listed as a boot option you can boot your computer to the **One Time Boot** Menu. If the option is listed, then the BIOS can be updated using this method.

To update your BIOS from the One-Time boot menu, you need the following:

- USB drive formatted to the FAT32 file system (the drive does not have to be bootable)
- BIOS executable file that you downloaded from the Dell Support website and copied to the root of the USB drive
- AC power adapter must be connected to the computer
- A functional computer battery to flash the BIOS

Perform the following steps to update the BIOS from the One-Time boot menu:

CAUTION: Do not turn off the computer during the BIOS flash update process. The computer may not boot if you turn off your computer.

Steps

- 1. Turn off the computer, insert the USB drive that contains the BIOS flash update file.
- 2. Turn on the computer and press **F12** to access the **One Time Boot** Menu. Select **BIOS Update** using the mouse or arrow keys then press Enter.

The flash BIOS menu is displayed.

- 3. Click Flash from file.
- 4. Select the external USB device.
- 5. Select the file and double-click the flash target file, and then click **Submit**.
- 6. Click Update BIOS. The computer restarts to flash the BIOS.
- 7. The computer will restart after the BIOS flash update is completed.

System and setup password

CAUTION: The password features provide a basic level of security for the data on your computer.

CAUTION: Ensure that your computer is locked when it is not in use. Anyone can access the data that is stored on your computer, when left unattended.

Table 37. System and setup password

Password type	Description
* '	Password that you must enter to boot to your operating system.
···	Password that you must enter to access and change the BIOS settings of your computer.

You can create a system password and a setup password to secure your computer.

NOTE: The System and setup password feature is disabled by default.

Assigning a System Setup password

Prerequisites

You can assign a new System or Admin Password only when the status is set to **Not Set**. To enter BIOS System Setup, press F2 immediately after a power-on or reboot.

Steps

- In the System BIOS or System Setup screen, select Security and press Enter.
 The Security screen is displayed.
- 2. Select System/Admin Password and create a password in the Enter the new password field.

Use the following guidelines to create the system password:

- A password can have up to 32 characters.
- A password can at least have one special character: "(! " # \$ % & ' * + , . / :; < = > ? @ [\] ^ _ ` { | })"
- A password can have numbers 0 to 9.
- A password can have an upper case letters from A to Z.
- A password can have a lower case letters from a to z.
- 3. Type the system password that you entered earlier in the Confirm new password field and click OK.
- 4. Press Y to save the changes.

The computer restarts.

Deleting or changing an existing system password or setup password

Prerequisites

Ensure that the **Password Status** is Unlocked in the System Setup before attempting to delete or change the existing system password and/or setup password. You cannot delete or change an existing system password or setup password if the **Password Status** is Locked. To enter the System Setup, press F2 immediately after a power-on or reboot.

Steps

- In the System BIOS or System Setup screen, select System Security and press Enter.
 The System Security screen is displayed.
- 2. In the System Security screen, verify that the Password Status is Unlocked.
- 3. Select System Password. Update or delete the existing system password, and press Enter or Tab.
- 4. Select **Setup Password**. Update or delete the existing setup password, and press Enter or Tab.
 - NOTE: If you change the system password and/or setup password, reenter the new password when prompted. If you delete the system password and/or setup password, confirm the deletion when prompted.
- 5. Press Esc. A message prompts you to save the changes.
- Press Y to save the changes and exit from System Setup. The computer restarts.

Clearing system and setup passwords

About this task

To clear the system or setup passwords, contact Dell technical support as described at Contact Support.

NOTE: For information about how to reset Windows or application passwords, see the documentation accompanying Windows or your application.

Troubleshooting

Dell SupportAssist Pre-boot System Performance Check diagnostics

About this task

SupportAssist diagnostics (also known as system diagnostics) performs a complete check of your hardware. The Dell SupportAssist Pre-boot System Performance Check diagnostics is embedded within the BIOS and launched by the BIOS internally. The embedded system diagnostics provides options for particular devices or device groups allowing you to:

- Run tests automatically or in an interactive mode.
- Repeat the tests.
- Display or save test results.
- Run thorough tests to add more options and obtain details about any failed devices.
- View status messages that inform you when the tests are completed successfully.
- View error messages that inform you of problems encountered during testing.
- NOTE: Some tests for specific devices require user interaction. Always ensure that you are present at the computer when the diagnostic tests are performed.

For more information, see the knowledge base article 000181163.

Running the SupportAssist Pre-Boot System Performance Check

Steps

- 1. Turn on your computer.
- 2. As the computer boots, press the F12 key.
- On the boot menu screen, select **Diagnostics**. The diagnostic quick test begins.
 - NOTE: For more information about running the SupportAssist Pre-Boot System Performance Check on a specific device, see Dell Support Site.
- **4.** If there are any issues, error codes are displayed. Note the error code and validation number and contact Dell.

Power-Supply Unit Built-in Self-Test

Built-in Self-Test (BIST) helps determine if the power-supply unit is working. To run self-test diagnostics on the power-supply unit of a desktop or all-in-one computer, search in the Knowledge Base Resource at Dell Support Site.

System-diagnostic lights

The power-button LED indicates the power status of the computer. These are the power states:

Solid white—Computer is in S0 state. This is the normal power state of the computer.

Blinking white—Computer is in a low-power state, S3. This does not indicate a fault.

Pulsing white—Computer is in the memory-training state, wait for the computer to boot up.

Solid amber—Computer is experiencing a boot failure, including the power-supply unit.

Blinking amber—Computer is experiencing a boot failure but the power-supply unit is functioning correctly.

Off—Computer is in sleep state, hibernation mode, or turned off.

The power-button LED may also blink amber or white according to predefined "beep codes" indicating various failures.

For example, the power-button LED blinks amber two times followed by a pause, and then blinks white three times followed by a pause. This 2,3 pattern continues until the computer is turned off, indicating no memory or RAM is detected.

The following table shows different power-button LED light patterns and associated problems.

NOTE: The following diagnostic light codes and recommended solutions are intended for Dell service technicians to troubleshoot problems. You should only perform troubleshooting and repairs as authorized or directed by the Dell technical support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty.

Table 38. Diagnostic light codes

Diagnostic light codes (Amber, White) Problem description	
1,2	Unrecoverable SPI Flash Failure
2,1	CPU configuration or CPU failure
2,2	System board: BIOS or Read-Only Memory (ROM) failure
2,3	No memory or Random-Access Memory (RAM) detected
2,4	Memory or Random-Access Memory (RAM) failure
2,5	Invalid memory installed
2,6	System board/Chipset Error/Clock failure/Gate A20 failure/Super I/O failure/Keyboard controller failure
3,1	CMOS battery failure
3,2	PCI of Video card/chip failure
3,3	BIOS Recovery 1: BIOS recovery image not found
3,4	BIOS Recovery 2: Recovery image found but invalid
3,5	Power Rail Failure: EC ran into power sequencing failure
3,6	Paid SPI Volume Error
3,7	Management Engine (ME) error. Timeout waiting on ME to reply to HECI message.
4,2	CPU Power cable connection issue

Recovering the operating system

When your computer is unable to boot to the operating system even after repeated attempts, it automatically starts Dell SupportAssist OS Recovery.

Dell SupportAssist OS Recovery is a stand-alone tool that is preinstalled in Dell computers running the Windows operating system. It consists of tools to diagnose and troubleshoot issues that may occur before your computer boots to the operating system. It enables you to diagnose hardware issues, repair your computer, back up your files, and restore your computer to its factory state.

You can also download it from the Dell Support website to troubleshoot and fix your computer when it fails to boot into the primary operating system due to software or hardware failures.

For more information about the Dell SupportAssist OS Recovery, see *Dell SupportAssist OS Recovery User's Guide* at Serviceability Tools at the Dell Support Site. Click **SupportAssist** and then click **SupportAssist OS Recovery**.

Real Time Clock—RTC reset

The Real Time Clock (RTC) reset function allows you or the service technician to recover the recently launched model Dell Latitude and Precision systems from **No POST/No Boot/No Power** situations. You can initiate the RTC reset on the system

from a power-off state only if it is connected to AC power. Press and hold the power button for 25 seconds. The system RTC reset occurs after you release the power button.

NOTE: If AC power is disconnected from the system during the process or the power button is held longer than 40 seconds, the RTC reset process gets aborted.

The RTC reset will reset the BIOS to Defaults, un-provision Intel vPro and reset the system date and time. The following items are unaffected by the RTC reset:

- Service Tag
- Asset Tag
- Ownership Tag
- Admin Password
- System Password
- HDD Password
- Key Databases
- System Logs

NOTE: The IT administrator's vPro account and password on the system will be un-provisioned. The system needs to go through the setup and configuration process again to reconnect it to the vPro server.

The below items may or may not reset based on your custom BIOS setting selections:

- Boot List
- Enable Legacy Option ROMs
- Secure Boot Enable
- Allow BIOS Downgrade

Backup media and recovery options

It is recommended to create a recovery drive to troubleshoot and fix problems that may occur with Windows. Dell provides multiple options for recovering the Windows operating system on your Dell computer. For more information, see Dell Windows Backup Media and Recovery Options.

Network power cycle

About this task

If your computer is unable to access the Internet due to network connectivity issues, reset your network devices by performing the following steps:

Steps

- 1. Turn off the computer.
- 2. Turn off the modem.
 - NOTE: Some Internet service providers (ISPs) provide a modem and router combo device.
- 3. Turn off the wireless router.
- 4. Wait for 30 seconds.
- 5. Turn on the wireless router.
- 6. Turn on the modem.
- 7. Turn on the computer.

Getting help and contacting Dell Technologies

Self-help resources

You can get information and help on Dell Technologies products and services using these self-help resources:

Table 39. Self-help resources

Self-help resources	Resource location
Information about Dell Technologies products and services	Dell Site
MyDell app	Dell
Tips	*
Contact Support	In Windows search, type Contact Support, and press Enter.
Online help for operating system	Windows Support Site
Access top solutions, diagnostics, drivers and downloads, and learn more about your computer through videos, manuals, and documents.	Your Dell Technologies computer is uniquely identified using a Service Tag or Express Service Code. To view relevant support resources for your Dell Technologies computer, enter the Service Tag or Express Service Code at Dell Support Site.
	For more information about how to find the Service Tag for your computer, see Instructions on how to find your Service Tag or Serial Number.
Dell Technologies knowledge base articles	 Go to Dell Support Site. On the menu bar at the top of the Support page, select Support > Support Library. In the Search field on the Support Library page, type the keyword, topic, or model number, and then click or tap the search icon to view the related articles.

Contacting Dell Technologies

To contact Dell Technologies for sales, technical support, or customer service issues, see Contact Support at Dell Support Site.

- (i) NOTE: Availability of the services may vary depending on the country or region, and product.
- NOTE: If you do not have an active Internet connection, you can find contact information about your purchase invoice, packing slip, bill, or Dell Technologies product catalog.