

# iiyama | Servicecard





# Dear user, we congratulate you on the purchase of your iiyama LCD.

For details on warranty and locally used pixel policies that apply directly after installation of your product please check the iiyama website.

### To report a fault, please contact your local support centre found at www.iiyama.com/service

#### Things to check before you call the iiyama information line

- if the power cable is connected securely and turned on?
- | if the display has been turned on?
- | if the signal cable is connected securely and the correct input selected?
- | if the computer has been restarted with the display connected?
- | if the graphics card is correctly installed with the latest drivers possible?
- | if the correct native resolution has been selected via 'Display Properties'?
- If the R/G/B signal configuration is correct?
- | if the displays On Screen Menu is shown?
- | if the correct brightness and contrast settings have been set?
- | if given display tolerances and compatibility have been considered?
- | if via the On Screen Menu you have performed a Factory Reset/Recall?

# Before reporting the screen defect, please prepare the following information/evidence:

model number \*

purchase receipt and serial number \*

name and address for collection

telephone/fax number, for availability during the day

- convenient collection date (date, time)
- short description of the defect

#### Important Note:


If there is no fault found in the collected equipment after inspection, the transferring party shall incur charges for transport and administration.

If you have checked all of the above and there is still no picture, call our information line for assistance in your country.









# Say hello to a more sustainable product

IT products are associated with a wide range of sustainability risks throughout their life cycle. Human rights violations are common in the factories. Harmful substances are used both in products and their manufacture. Products can often have a short lifespan because of poor ergonomics, low quality and when they are not able to be repaired or upgraded.

This product is a better choice. It meets all the criteria in TCO Certified, the world's most comprehensive sustainability certification for IT products. Thank you for making a responsible product choice, that help drive progress towards a more sustainable future!

Criteria in TCO Certified have a life-cycle perspective and balance environmental and social responsibility. Conformity is verified by independent and approved verifiers that specialize in IT products, social responsibility or other sustainability issues. Verification is done both before and after the certificate is issued, covering the entire validity period. The process also includes ensuring that corrective actions are implemented in all cases of factory non-conformities. And last but not least, to make sure that the certification and independent verification is accurate, both TCO Certified and the verifiers are reviewed regularly.

# Want to know more?

Read information about TCO Certified, full criteria documents, news and updates at **tcocertified.com.** On the website you'll also find our Product Finder, which presents a complete, searchable listing of certified products.

# **CE MARKING DECLARATION OF CONFORMITY**

This LCD monitor complies with the requirements of the EC/EU Directive 2014/30/EU "EMC Directive", 2014/35/EU "Low Voltage Directive", 2009/125/EC "ErP Directive" and 2011/65/EU "RoHS Directive".

The electro-magnetic susceptibility has been chosen at a level that gives correct operation in residential areas, business and light industrial premises and small-scale enterprises, inside as well as outside of the buildings. All places of operation are characterised by their connection to the public low voltage power supply system.

IIYAMA CORPORATION: Wijkermeerstraat 8, 2131 HA Hoofddorp, The Netherlands

Model No. : PL2792Q



We recommend recycling of used product. Please contact your dealer or iiyama service center. Recycle information is obtained via the Internet, using the address: http://www.iiyama.com

You can access the Web page of different countries from there.

- We reserve the right to change specifications without notice.
- All trademarks used in this user manual are the property of their respective owners.
- The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.
- Eprel registration number XUB2792QSU-B1 C : 360721, XUB2792QSU-W1 C : 360740 XU2792QSU-B1 A : 360750

# ENGLISH

# TABLE OF CONTENTS

| FOR YOUR SAFETY                                  | 1  |
|--|----|
| SAFETY PRECAUTIONS                               | 1  |
| SPECIAL NOTES ON LCD MONITORS                    | 3  |
| CUSTOMER SERVICE                                 | 3  |
| CLEANING   | 3  |
| BEFORE YOU OPERATE THE MONITOR                   | 4  |
| FEATURES   | 4  |
| CHECKING THE CONTENTS OF THE PACKAGE             | 4  |
| INSTALLATION                                     | 5  |
| FITTING AND REMOVAL OF BASE : ProLite XUB2792QSU | 7  |
| FITTING AND REMOVAL OF BASE : ProLite XU2792QSU  | 8  |
| CONTROLS AND CONNECTORS : ProLite XUB2792QSU     | 9  |
| CONTROLS AND CONNECTORS : ProLite XU2792QSU      | 10 |
| CONNECTING YOUR MONITOR : ProLite XUB2792QSU     | 11 |
| CONNECTING YOUR MONITOR : ProLite XU2792QSU      | 12 |
| DISCONNECTING YOUR MONITOR                       | 13 |
| COMPUTER SETTING                                 | 13 |
| ADJUSTING THE HEIGHT AND THE VIEWING ANGLE :     |    |
| ProLite XUB2792QSU                               | 13 |
| ADJUSTING THE VIEWING ANGLE : ProLite XU2792QSU  | 14 |
| OPERATING THE MONITOR                            | 15 |
| ADJUSTMENT MENU CONTENTS                         | 16 |
| STANDBY FEATURE                                  | 23 |
| TROUBLE SHOOTING                                 | 24 |
| RECYCLING INFORMATION                            | 25 |
| APPENDIX   | 26 |
| SPECIFICATIONS : ProLite XUB2792QSU              | 26 |
| SPECIFICATIONS : ProLite XU2792QSU               | 27 |
| DIMENSIONS : ProLite XUB2792QSU                  | 28 |
| DIMENSIONS : ProLite XU2792QSU                   | 28 |
| COMPLIANT TIMING                                 | 29 |

# ENGLISH

# FOR YOUR SAFETY

# SAFETY PRECAUTIONS

#### WARNING

#### STOP OPERATING THE MONITOR WHEN YOU SENSE TROUBLE

If you notice any abnormal phenomena such as smoke, strange sounds or fumes, unplug the monitor and contact your dealer or iiyama service center immediately. Further use may be dangerous and can cause fire or electric shock.

#### NEVER REMOVE THE CABINET

High voltage circuits are inside the monitor. Removing the cabinet may expose you to the danger of fire or electric shock.

#### DO NOT PUT ANY OBJECT INTO THE MONITOR

Do not put any solid objects or liquids such as water into the monitor. In case of an accident, unplug your monitor immediately and contact your dealer or iiyama service center. Using the monitor with any object inside may cause fire, electric shock or damage.

#### **INSTALL THE MONITOR ON A FLAT, STABLE SURFACE**

The monitor may cause an injury if it falls or is dropped.

#### DO NOT USE THE MONITOR NEAR WATER

Do not use where water may be splashed or spilt onto the monitor as it may cause fire or electric shock.

#### **OPERATE UNDER THE SPECIFIED POWER SUPPLY**

Be sure to operate the monitor only with the specified power supply. Use of an incorrect voltage will cause malfunction and may cause fire or electric shock.

#### **PROTECT THE CABLES**

Do not pull or bend the power cable and signal cable. Do not place the monitor or any other heavy objects on the cables. If damaged, the cables may cause fire or electric shock.

#### **ADVERSE WEATHER CONDITIONS**

It is advisable not to operate the monitor during a heavy thunder storm as the continual breaks in power may cause malfunction. It is also advised not to touch the plug in these circumstances as it may cause electric shock.

#### CAUTION

#### **INSTALLATION LOCATION**

Do not install the monitor where sudden temperature changes may occur, or in humid, dusty or smoky areas as it may cause fire, electric shock or damage. You should also avoid areas where the sun shines directly on the monitor.

#### DO NOT PLACE THE MONITOR IN A HAZARDOUS POSITION

The monitor may topple and cause injury if not suitably located. Please also ensure that you do not place any heavy objects on the monitor, and that all cables are routed such that children may not pull the cables and possibly cause injury.

#### MAINTAIN GOOD VENTILATION

Ventilation slots are provided to keep the monitor from overheating. Covering the slots may cause fire. To allow adequate air circulation, place the monitor at least 10 cm (or 4 inches) from any walls. When removing the tilt stand, the ventilation slots on the back side of the monitor can be blocked. This may overheat the monitor and may cause fire or damage. Make sure to allow enough ventilation when removing the tilt stand. Operating the monitor on its back, side, upside down or on a carpet or any other soft material may also cause damage.

#### DISCONNECT THE CABLES WHEN YOU MOVE THE MONITOR

When you move the monitor, turn off the power switch, unplug the monitor and be sure the signal cable is disconnected. If you do not disconnect them, it may cause fire or electric shock.

#### **UNPLUG THE MONITOR**

If the monitor is not in use for a long period of time it is recommended that it is left unplugged to avoid accidents.

#### HOLD THE PLUG WHEN DISCONNECTING

To disconnect the power cable or signal cable, always pull it by the plug. Never pull on the cable itself as this may cause fire or electric shock.

#### DO NOT TOUCH THE PLUG WITH WET HANDS

Pulling or inserting the plug with wet hands may cause electric shock.

#### WHEN YOU INSTALL THE MONITOR ON YOUR COMPUTER

Be sure the computer is strong enough to hold the weight of the monitor, otherwise, you may damage your computer.

#### **CAREFUL! PROTECT YOUR HANDS AND FINGERS**

- Be careful not to hurt your fingers or hands when you change the height or the angle.
- Injury can occur if care is not taken to avoid finger contact with the displays base when adjusting the height. (Just for height adjustable model.)

#### **REMARK FOR 24/7 USAGE**

This product is not specifically designed for 24/7 usage in all environments.

#### **OTHERS**

#### **ERGONOMIC RECOMMENDATIONS**

To eliminate eye fatigue, do not operate the monitor against a bright background or in a dark room. For optimal viewing comfort, the monitor should be just below eye level and 40-60 cm (16-24 inches) away from your eyes. When using the monitor over a prolonged time, a ten minute break every hour is recommended as looking at the screen continuously can cause eye strain.

# ENGLISH

### SPECIAL NOTES ON LCD MONITORS

The following symptoms are normal with LCD monitors and do not indicate a problem.

- **NOTE** When you first turn on the LCD monitor, the picture may not fit in the display area because of the type of computer that is used. In this case, adjust the picture position to the correct position.
  - You may find slightly uneven brightness on the screen depending on the desktop pattern you use.
  - Due to the nature of the LCD screen, an afterimage of the previous screen may remain after switching the image, when the same image is displayed for hours. In this case, the screen can be recovered slowly by changing the image or turning off the Power Switch for some hours.

# **CUSTOMER SERVICE**

NOTE If you have to return your unit for service and the original packaging has been discarded, please contact your dealer or iiyama service center for advice or replacement packaging.

# CLEANING

- **WARNING** If you drop any materials or liquids such as water into the monitor when cleaning, unplug the power cable immediately and contact your dealer or iiyama service center.
- **CAUTION** For safety reasons, turn off the power switch and unplug the monitor before you clean it.

#### NOTE

- To protect the LCD panel, do not scratch or rub the screen with a hard object.
- Never use any of the following strong solvents. These will damage the cabinet and the LCD screen.

| Thinner          | Spray-type cleaner       |
|------------------|--------------------------|
| Benzine          | Wax                      |
| Abrasive cleaner | Acid or Alkaline solvent |

- Touching the cabinet with any product made from rubber or plastic for a long time may cause degeneration or loss of paint on the cabinet.
- **CABINET** Stains can be removed with a cloth lightly moistened with a mild detergent solvent. Then wipe the cabinet with a soft dry cloth.
- LCD Periodic cleaning with a soft dry cloth is recommended.
- **SCREEN** Don't use tissue paper etc. because these will damage the LCD screen.

# BEFORE YOU OPERATE THE MONITOR

# **FEATURES**

- Supports Resolutions up to 2560 × 1440
- High Contrast 1000:1 (Typical), Adv. Contrast Function Available / Brightness 350cd/m<sup>2</sup> (Typical)
- Supports AMD Radeon FreeSync<sup>™</sup> Technology
- Quick Response Time 5ms (Gray to Gray)
- Blue Light Reducer
- Digital Character Smoothing
- 2 × 2W Stereo Speakers
- Standby Feature (VESA DPMS Compliant)
- VESA Mounting Standard (100mm×100mm) Compliant
- Keyhole for Security Lock

# CHECKING THE CONTENTS OF THE PACKAGE


The following accessories are included in your package. Check to see if they are enclosed with the monitor. If anything is missing or damaged, please contact your local iiyama dealer or regional iivama office.

- Power Cable\*<sup>1</sup>
- HDMI Cable
- USB Cable
- Cable Holder\*<sup>2</sup>
- Stand-Base with a screw Stand-Neck\*<sup>2</sup>
- DisplayPort Cable
- Safety Guide
- Quick Start Guide
- CAUTION \*1 The rating of the Power Cable enclosed in 120V area is 10A/125V. If you are using a power supply higher than this rating, then a power cable with a rating of 10A/ 250V must be used. However, all guarantees and warranties are void for any problems or damage caused by a power cable not supplied by iiyama. An approved power cable greater or equal to H05VVF. 3G. 0.75mm<sup>2</sup> must be used.
  - \*2 Accessory for ProLite XU2792QSU

**WARNING** ■ Before installation, make sure the wall, ceiling or desktop arm is strong enough to hold the necessary weight of the display and the mount.

#### < WALL MOUNTING >


WARNING When you use with the wall mounting, in consideration of thickness of the mounting stage, tighten the M4 Screws (4pcs) with washer which "L" length is 7mm to fasten the monitor. Using the screw longer than this may cause electric shock or damage because it may contact with the electrical parts inside the monitor.



#### < ROTATING THE MONITOR >

#### ProLite XUB2792QSU

The monitor is designed to be compatible with both landscape and portrait modes. Video card for portrait display will be required for rotating the image on the screen.




#### With Stand:

- **NOTE** Adjust the monitor's height before panel rotation.
  - Attempting to rotate the panel forcibly without adjusting the stand height may cause damage to the panel or the stand.

#### ProLite XU2792QSU

The monitor is designed to be compatible only with the landscape mode.




# FITTING AND REMOVAL OF BASE : ProLite XUB2792QSU

#### CAUTION

- Put the monitor on a stable surface. The monitor may cause injury or damage if it falls or is dropped.
- Do not give a strong impact to the monitor. It may cause damage.
- Unplug the monitor before removal or installation to avoid an electric shock or a damage.

#### <Installation>

- ① Put a piece of soft cloth on the table beforehand to prevent the monitor from being scratched. Lay the monitor flat on a table with front face down.
- ② Install the Stand-Base as shown on below picture.
- 3 Tighten the 'thumb screw' to secure the Stand-Base to the monitor.



#### <Removal>

- ① Put a piece of soft cloth on the table beforehand to prevent the monitor from being scratched. Lay the monitor flat on a table with front face down.
- 2 Loosen the 'thumb screw' to remove the Stand-Base from the monitor.


# FITTING AND REMOVAL OF BASE : ProLite XU2792QSU


CAUTION

- Put the monitor on a stable surface. The monitor may cause injury or damage if it falls or is dropped.
- Do not give a strong impact to the monitor. It may cause damage.
- Unplug the monitor before removal or installation to avoid an electric shock or a damage.

#### <Installation>


- ① Put a piece of soft cloth on the table beforehand to prevent the monitor from being scratched. Lay the monitor flat on a table with front face down.
- ② Hold the monitor and install the Stand-Neck to the monitor. Secure it with the screw provided.
- ③ Install the Stand-Base to the Stand-Neck.
- ④ Tighten the 'thumb screw' to secure the Stand-Base to the monitor.
- 5 Place the Cable Holder.







#### <Removal>


- ① Put a piece of soft cloth on the table beforehand to prevent the monitor from being scratched. Lay the monitor flat on a table with front face down.
- ② Loosen the 'thumb screw' to remove the Stand-Base from the monitor.
- ③ Loosen the screw to remove the Stand-Neck.
- ④ Pull the hook of the Cable Holder outside and remove it.







# **CONTROLS AND CONNECTORS : ProLite XUB2792QSU**



<Back>

① Power Indicator

 NOTE
 Blue:
 Normal operation


 Orange:
 Standby mode

- ② Power Switch ( 也)
- ③ Menu / Select Button (ENTER)
- ④ Scroll Up / Volume Button ( ► / 📢 )
- (5) Scroll Down / ECO Mode Button (  $\checkmark$  /  $\bigcirc$  )
- ⑥ Exit Button (EXIT)
- ⑦ Input Select Button (INPUT)
- ⑧ Speakers
- (9) USB Downstream Connectors (~~ 5V, 900mA)
- 1 USB Upstream Connector (
- (1) Keyhole for Security Lock

**NOTE** You can fasten a security lock and cable to prevent the monitor from being removed without your permission.

- DisplayPort Connector (DP)
- 13 HDMI Connector (HDMI)
- I DVI-D Connector (DVI-D)
- 15 Cable Hole
- 16 Headphone Connector (LINE OUT)
- 1 Audio Connector (LINE IN)
- (18) AC Connector (  $\sim$  : Alternating current)

# CONTROLS AND CONNECTORS : ProLite XU2792QSU



- Power Indicator
   NOTE Blue: Normal operation
   Orange: Standby mode
- ② Power Switch ())
- ③ Menu / Select Button (ENTER)
- ④ Scroll Up / Volume Button ( ► / 🗹 )
- ⑤ Scroll Down / ECO Mode Button ( ◀ / ∅ )
- 6 Exit Button (EXIT)
- ⑦ Input Select Button (INPUT)
- ⑧ Speakers
- ⑨ USB Downstream Connectors (⊶⇔ 5V, 900mA)
- ① USB Upstream Connector (⊶ )
- (1) Keyhole for Security Lock

**NOTE** You can fasten a security lock and cable to prevent the monitor from being removed without your permission.


- 1 DisplayPort Connector (DP)
- 1 HDMI Connector (HDMI)
- (1) DVI-D Connector (DVI-D)
- (15) Cable Holder
- (16) Headphone Connector (LINE OUT)
- 1 Audio Connector (LINE IN)
- (18) AC Connector (  $\sim$  : Alternating current)

## CONNECTING YOUR MONITOR : ProLite XUB2792QSU

- 1 Ensure that both the computer and the monitor are switched off.
- ② Connect the computer to the monitor with the signal cable.
- ③ Connect the monitor to the audio equipment with the audio cable for computer when using the audio features.
- ④ Connect the Power Cable to the monitor first and then to the power source.
- (5) Turn on your monitor and computer.

NOTE Make sure that the building installation has a circuit breaker of 120/240V, 20A (maximum).


- The signal cables used for connecting the computer and monitor may vary with the type of computer used. An incorrect connection may cause serious damage to both the monitor and the computer. The cable supplied with the monitor is for a standard connector. If a special cable is required please contact your local iiyama dealer or regional iiyama office.
- Make sure you tighten the finger screws at each end of the signal cable.
- The Class I pluggable equipment Type A must be connected to protective earth.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- Excessive sound pressure from ear-/headphones can cause hearing damage/hearing loss.



\* DVI dual-link cable is not supplied with the monitor. If you use low quality DVI dual-link cable, it may cause a result of electro-magnetic interference. Please contact the iiyama Support Centre in your country if you wish to connect the monitor via the DVI input.

#### [Collect Cables]

Put the cables through the Cable Hole to bundle them.




# CONNECTING YOUR MONITOR : ProLite XU2792QSU

- 1 Ensure that both the computer and the monitor are switched off.
- ② Connect the computer to the monitor with the signal cable.
- ③ Connect the monitor to the audio equipment with the audio cable for computer when using the audio features.
- ④ Connect the Power Cable to the monitor first and then to the power source.
- (5) Turn on your monitor and computer.

NOTE Make sure that the building installation has a circuit breaker of 120/240V, 20A (maximum).


- The signal cables used for connecting the computer and monitor may vary with the type of computer used. An incorrect connection may cause serious damage to both the monitor and the computer. The cable supplied with the monitor is for a standard connector. If a special cable is required please contact your local iiyama dealer or regional iiyama office.
- Make sure you tighten the finger screws at each end of the signal cable.
- The Class I pluggable equipment Type A must be connected to protective earth.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- Excessive sound pressure from ear-/headphones can cause hearing damage/hearing loss.



\* DVI dual-link cable is not supplied with the monitor. If you use low quality DVI dual-link cable, it may cause a result of electro-magnetic interference. Please contact the iiyama Support Centre in your country if you wish to connect the monitor via the DVI input.

#### [ Collect Cables ]

Put the cables through the Cable Holder to bundle them.



### **DISCONNECTING YOUR MONITOR**

- ① Ensure that both the computer and the monitor are switched off.
- ② Disconnect the power source first and then the Power Cable from the monitor.
- 3 Disconnect the audio cable from the computer and the monitor.
- 4 Disconnect the USB cable from the computer and the monitor.
- (5) Disconnect the signal cable from the computer and the monitor.


# COMPUTER SETTING


Signal Timing

Change to the desired signal timing listed on page 29: COMPLIANT TIMING.

#### ADJUSTING THE HEIGHT AND THE VIEWING ANGLE : ProLite XUB2792QSU

- For optimal viewing it is recommended to position yourself directly opposite to the full face of the monitor, then adjust the monitor's height and angle to your own preference.
- Hold the panel so that the monitor does not topple when you change the monitor's height or angle.
- You are able to adjust the monitor's height up to 130mm, angle up to 45° right and left, 22° upward and 5° downward.
- NOTE Do not touch the LCD screen when you change the height or the angle. It may cause damage or break the LCD screen.
  - Careful attention is required not to pinch your fingers or hands into the moving part of the stand when you change the height or the angle.
  - Injury can occur if care is not taken to avoid finger contact with the displays base when adjusting the height.








# ADJUSTING THE VIEWING ANGLE : ProLite XU2792QSU

- For optimal viewing it is recommended to look at the full face of the monitor.
- Hold the stand so that the monitor does not topple when you change the monitor's angle.
- You are able to adjust the monitor's angle up to 22° upward, 5° downward.
- In order to ensure a healthy and relaxed body position when using the monitor at visual display workstations, it is recommended that the adjusted tilt angle should not exceed 10 degrees. Adjust the monitor's angle to your own preference.
- NOTE
  - Do not touch the LCD screen when you change the angle. It may cause damage or break the LCD screen.
    - Careful attention is required not to pinch your fingers or hands into the moving part of the stand when you change the angle.




# ENGLISH

# **OPERATING THE MONITOR**

To create the best picture, your iiyama LCD monitor has been preset at the factory with the COMPLIANT TIMING shown on page 29. You are also able to adjust the picture by following the button operation shown below.

- Press the ENTER Button to start the On Screen Display feature. There are additional Menu items which can be switched by using the ◀ / ▶ Buttons.
- ② Select the Menu item which contains the adjustment icon relating to the adjustment you want to make. Press the ENTER Button. Then, use the ◀ / ▶ Buttons to highlight the desired adjustment icon.
- ③ Press the ENTER Button again. Use the ◀ / ▶ Buttons to make the appropriate adjustment or setting.
- ④ Press the EXIT Button to leave the menu, and the settings you just made would be automatically saved.

For example, to correct for OSD vertical position, select Menu item of Setup Menu and then press the ENTER Button. Then, select OSD Position by using the  $\blacktriangleleft$  /  $\blacktriangleright$  Buttons. An adjustment page appears after you press the ENTER Button. Then, select V.Position by using the  $\blacktriangleleft$  /  $\blacktriangleright$  Buttons. An adjustment page appears after you press the ENTER Button.



Then, use the  $\triangleleft$  /  $\triangleright$  Buttons to change the OSD vertical position settings. The OSD vertical position of the overall display should be changing accordingly while you are doing this.

| Setup Menu  |      |
|-------------|------|
| V. Position |      |
|             | > 50 |

Press the EXIT Button lastly, it ends, all changes are saved in the memory.

#### NOTE

- When button operations are aborted during adjustment, On-Screen Display disappears when the time set for the OSD Time Out has passed. Also, press the EXIT button to quickly turn off the On-Screen Display.
- Any changes are automatically saved in the memory when the On Screen Display disappears. Turning off the power should be avoided while using the Menu.
- All adjustments have only one setting which applies to all signal timings.



# **ADJUSTMENT MENU CONTENTS**

| Picture Adjust *3             |                        |  |                             |
|-------------------------------|------------------------|--|-----------------------------|
| Adjustment Item               | Probler                | m / Option   | Button to Press             |
| Contrast *2                   | Too dull<br>Too intens | e  | \$<br>\$                    |
| Brightness * <sup>1.2,4</sup> | Too dark<br>Too bright |  | • • •<br>• • •              |
| Overdrive                     |                        | -2<br>ve the gray level response tir<br>evel results in a faster res |                             |
|                               | Off                    | Typical Contrast Ratio   |                             |
| Adv. Contrast                 | On                     | Increased Contrast Ratio   |                             |
|                               | Off                    | Normal   |                             |
| ECO Mode Direct               | Mode1                  | Brightness of back-light is reduced.                                 |                             |
|                               | Mode2                  | Brightness of back-light is reduced more than Mode1                  |                             |
|                               | Mode3                  | Brightness of back-light   | is reduced more than Mode2. |
|                               | Off                    | Typical  |                             |
| Plue Light Peducer            | Mode1                  | Blue light is reduced.   |                             |
| Blue Light Reducer            | Mode2                  | Blue light is reduced more than Mode1.                               |                             |
|                               | Mode3                  | Blue light is reduced m  | ore than Mode2.             |

\*<sup>1</sup> Adjust the Brightness when you are using the monitor in a dark room and feel the screen is too bright.

\*<sup>2</sup> Contrast and Brightness adjustments are disabled when Adv. Contrast mode is activated.

\*<sup>3</sup> Picture Adjust adjustment is disabled when i-Style Color is activated.

\*<sup>4</sup> Brightness adjustment is disabled when ECO Mode is activated.

# Direct

You can skip the Menu items and display an adjustment scale directly by using the following button operations.

• ECO Mode : Press the 
Button when the Menu is not displayed.

| 12 Input Select  |             |   |                        |
|--|-------------|---|------------------------|
| Adjustment Item  | Problem / C | Option                                    | Button to Press        |
|  | DVI         | Select the Digital (DVI) input.           |                        |
|  | HDMI        | Select the Digital (HDMI) input.          |                        |
| Input Select Dire  | DisplayPort | Select the Digital (DisplayPort) input.   |                        |
|  | Auto        | Search for an available in automatically. | nput source and select |
| <b>NOTE</b> Input source is fixed, not selected automatically when DVI, HDMI and DisplayPort which are selected. |             |   |                        |

# Direct

You can skip the Menu items and display an adjustment scale directly by using the following button operations.

• Input Select : Press the INPUT Button when the Menu is not displayed.

| □(J)) Audio Adjust  |                                    |                           |                          |  |
|---|------------------------------------|---------------------------|--------------------------|--|
| Adjustment Item   | Problem /                          | Option                    | Button to Press          |  |
| Volume Direct   | Too soft<br>Too loud               |                           | \$<br>\$                 |  |
| Mute  | Off                                | Return the sound volume   | e to the previous level. |  |
| Mute  | On Turn off the sound temporarily. |                           | orarily.                 |  |
| NOTE Mute On and Off are switched as follows by pressing the ▶ Button successively. |                                    |                           |                          |  |
|   | Line-In                            | Select the Line-In input. |                          |  |
| Digital Audio *   | HDMI                               | Select the HDMI input.    |                          |  |
|   | DisplayPort                        | Select the DisplayPort in | iput.                    |  |

\* Suitable for HDMI/DisplayPort input only.

# Direct

You can skip the Menu items and display an adjustment scale directly by using the following button operations.

• Volume : Press the > Button when the Menu is not displayed.

# 💬 Color Adjust

| Adjustment Item  | Probler    | m / Option Button to Press   |
|------------------|------------|--|
| Cool *1          | Cool color |  |
| Normal *1        | Normal co  | or   |
| Warm *1          | Warm colo  | r  |
|                  | Red        |  |
| User Color *1    | Green      | Too weak   |
|                  | Blue       |  |
|                  | Off        | Return to a state set by color adjustment except<br>i-Style Color. |
|                  | Standard   | For general windows environment and monitor default setting.       |
| i-Style Color *2 | Game       | For PC game environment.   |
|                  | Cinema     | For movie and video environment.                                   |
|                  | Scenery    | For displaying outdoor scenery images                              |
|                  | Text       | For text editing and viewing in a word processing environment.     |

\*<sup>1</sup> Cool, Normal, Warm and User Color adjustments are disabled when i-Style Color or Blue Light Reducer is activated.

\*<sup>2</sup> i-Style Color adjustment is disabled when Blue Light Reducer is activated.

| Image Adjust        |   |   |                                |
|---------------------|---|---|--------------------------------|
| Adjustment Item     | Problem / C   | Option  | Button to Press                |
| Sharpness           | (sharp to soft).<br>Press the ▶ B<br>numerical orde | ge the picture quality fro<br>utton to change the pic<br>er. Press the ◀ Button<br>in reverse numerical o | cture quality in to change the |
| Video Mode Adjust * | Full Screen<br>Aspect Ratio                         | Expansion display<br>Expansion display of   | Aspect                         |

\* Only HDMI/DisplayPort input.


ſ

| ુે@ Language    |           |         |            |                    |
|-----------------|-----------|---------|------------|--------------------|
| Adjustment Item | Problem / | Option  |            | Button to Press    |
|                 | English   | English | Nederlands | Dutch              |
|                 | Français  | French  | Ĉesky      | Czech              |
|                 | Deutsch   | German  | Русский    | Russian            |
| Language        | Italiano  | Italian | 日本語        | Japanese           |
|                 | Polski    | Polish  | 简体中文       | Simplified Chinese |
|                 | Español   | Spanish |            |                    |

Setup

| Adjustment Item   | Proble                               | em / Option Button to Press   |  |
|---|--------------------------------------|---|--|
| OSD Position  | H.Positior                           | OSD is too left<br>OSD is too right                                 |  |
|   | V.Position                           | OSD is too low<br>OSD is too high                                   |  |
| OSD Time Out  | 11                                   | You can set the OSD display duration time between 5 and 30 seconds. |  |
| Opening Logo  | 11()#                                | iiyama Logo does not display when the monitor is turned on.         |  |
|   | On                                   | iiyama Logo displayed when the monitor is turned on.                |  |
| Auto Power - Off  | Off                                  | Off Auto Power - Off function is turned Off.                        |  |
| Auto Fower - On   | On                                   | Enable the Auto Power - Off function.                               |  |
| <b>NOTE</b> The Auto Power - Off function is enabled as default setting. Monitor will turn off automatically after 3 hours without any key operation. If you prefer to use the monitor over 3 hours continuously, please disable The Auto Power - Off function. |                                      |   |  |
| <b>F</b> ac. (0, m, c, †  | Off FreeSync function is turned Off. |   |  |
| FreeSync *  | On                                   | Enable the FreeSync function.                                       |  |

\* Only DisplayPort input.



| Reset           | _   |                                  |                 |
|-----------------|-----|----------------------------------|-----------------|
| Adjustment Item | Pro | blem / Option                    | Button to Press |
| Reset All       | No  | Return to Menu.                  |                 |
|                 | Yes | Factory-preset data is restored. |                 |

#### Lock Mode

#### <OSD Menu>

- 1. The OSD lock will be activated by pressing the front button ENTER for about 10 seconds. If you try to access the OSD by pressing any of the buttons, message "OSD Locked" will appear on the screen.
- 2. The OSD lock will be deactivated by pressing the front button ENTER again for about 10 seconds.

#### <Power Switch>

- 1. The power switch lock will be activated by pressing the front button ◀ for about 10 seconds. Locking the power switch means that won't be able to turn off the Monitor while the power switch is locked. If presses the power switch message "Power Button Locked" will appear on the screen.
- 2. The power switch lock will be deactivated by pressing the front button < again for about 10 seconds.


## STANDBY FEATURE

The standby feature of this product complies with power saving requirement of VESA DPMS. When activated, it automatically reduces unnecessary power consumption of the monitor when your computer is not in use.

To use the feature, the monitor needs to be connected to a VESA DPMS compliant computer. There is a standby step the monitor takes as described below. The standby function, including any timer settings is configured by the operating system. Check your operating system manual for information on how this can be configured.

#### Standby Mode

When the video signal from the computer is off, the monitor enters into Standby Mode which reduces the power consumption to less than 0.5W\*. The screen becomes dark, and the power indicator turns to orange. From Standby Mode, the image reappears in several seconds when either the keyboard or the mouse are touched again.



- \* USB peripheral and audio equipment are not connected.
- **NOTE** Even when using the standby mode, the monitor consumes electricity. Turn off the Power Switch whenever the monitor is not in use, during the night and weekends, to avoid unnecessary power consumption.

# **TROUBLE SHOOTING**

If the monitor fails to operate correctly, please follow the steps below for a possible solution.

- 1. Perform the adjustments described in OPERATING THE MONITOR, depending on the problem you have. If the monitor does not get a picture, skip to 2.
- 2. Consult the following items if you cannot find an appropriate adjustment item in OPERATING THE MONITOR or if the problem persists.
- 3. If you are experiencing a problem which is not described below or you cannot correct the problem, discontinue using the monitor and contact your dealer or iiyama service center for further assistance.

#### Problem

#### Check

#### 1 The picture does not appear. (Power indicator □ The Power Cable is firmly seated in the socket. does not light up.) □ The Power Switch is turned ON. □ The AC socket is live. Please check with another piece of equipment. (Power indicator D If the blank screen saver is in active mode, touch the keyboard or the is blue.) mouse. □ Increase the Contrast and/or Brightness. □ The computer is ON. □ The Signal Cable is properly connected. □ The signal timing of the computer is within the specification of the monitor. (Power indicator $\Box$ If the monitor is in standby mode, touch the keyboard or the mouse. is orange.) □ The computer is ON. □ The Signal Cable is properly connected. □ The signal timing of the computer is within the specification of the monitor. (2) The screen is not The Signal Cable is properly connected. synchronized. The signal timing of the computer is within the specification of the monitor. ③ The screen The signal timing of the computer is within the specification of the monitor. position is not in the center. ④ The screen is too □ The video output level of the computer is within the specification of the

bright or too dark. monitor.

#### Problem

#### Check

- (5) The screen is shaking.
   □ The power voltage is within the specification of the monitor.
   □ The signal timing of the computer is within the specification of the monitor.
   (6) No sound.
   □ The audio equipment (computer etc.) is ON.
   □ The audio cable is properly connected.
  - ☐ The Volume is turned up.
  - ☐ The Mute is OFF.
  - □ The audio output level of the audio equipment is within the specification of the monitor.
- The sound is too 
   The audio output level of the audio equipment is within the specification
   loud or too quiet.
   of the monitor.
- ⑧ A strange noise is □ The audio cable is properly connected. heard.

# **RECYCLING INFORMATION**

For better environment protection please don't dispose your monitor. Please visit our web site: www.iiyama.com for monitor recycling.

# APPENDIX

Design and specifications are subject to change without prior notice.

# SPECIFICATIONS : ProLite XUB2792QSU

| Size Cate            | egory                    | 27"   |  |  |
|----------------------|--------------------------|---|--|--|
|                      | Panel technology         | IPS (In-Plane-Switching)  |  |  |
|                      | Size                     | Diagonal: 27" (68.5cm)  |  |  |
|                      | Pixel pitch              | 0.233mm H × 0.233mm V   |  |  |
| LCD<br>Panel         | Brightness               | 350cd/m <sup>2</sup> (Typical)  |  |  |
| Fallel               | Contrast ratio           | 1000 : 1 (Typical), Adv. Contrast Function Available  |  |  |
|                      | Viewable angle           | Right / Left: 89 degrees each, Up / Down: 89 degrees each (Typical)   |  |  |
|                      | Response time            | 5ms (Gray to Gray)  |  |  |
| Display C            | Colors                   | 1.07 Billion  |  |  |
| Sync Fre             | quency                   | DVI: Horizontal: 30.0-89.0kHz, Vertical: 55-75Hz<br>HDMI: Horizontal: 30.0-89.0kHz, Vertical: 55-75Hz<br>DisplayPort(without FreeSync): Horizontal: 30.0-89.0kHz, Vertical: 50-75Hz<br>DisplayPort(with FreeSync): Horizontal: 30.0-115.0kHz, Vertical: 48-70Hz |  |  |
| Native Re            | esolution                | 2560 × 1440, 3.7 MegaPixels   |  |  |
| Support r            | nax. resolution          | DVI: 2560 × 1440 60Hz<br>HDMI: 2560 × 1440 60Hz<br>DisplayPort(without FreeSync): 2560 × 1440 70Hz<br>DisplayPort(with FreeSync): 2560 × 1440 70Hz  |  |  |
| Input Cor            | nnector                  | DVI-D, HDMI, DisplayPort  |  |  |
| Plug & Pl            | ау                       | VESA DDC2B <sup>™</sup>   |  |  |
| Input Vide           | eo Signal                | DVI (Digital Visual Interface Standard Rev.1.0) compliance<br>HDMI, DisplayPort   |  |  |
| USB Star             | ndard                    | USB3.0 (DC5V, 900mA)  |  |  |
| Number of Connector  | of USB Ports<br>or shape | 1 Upstream : Series B<br>2 Downstream : Series A  |  |  |
| Input Auc            | lio Connector            | ø 3.5mm mini jack (Stereo)  |  |  |
| Input Auc            | lio Signal               | 1.0Vrms maximum   |  |  |
| Headpho              | ne Connector             | ø 3.5mm mini jack (Stereo)  |  |  |
| Speakers             | ;                        | 2W × 2 (Stereo speakers)  |  |  |
| Maximum              | n Screen Size            | 596.7mm W × 335.7mm H / 23.5" W × 13.2" H   |  |  |
| Power So             | ource                    | 100-240VAC, 50/60Hz, 1.5A   |  |  |
| Power Co             | onsumption*              | 33W typical, Standby mode: 0.5W maximum   |  |  |
| Dimensio             | ns / Net Weight          | 611.0× 413.0 - 543.0 × 230.0mm / 24.1 × 16.3 - 21.4 × 9.1" (W×H×D<br>7.7kg / 17.0lbs  |  |  |
| Angle                |                          | Tilt: Upward: 22 degrees Downward: 5 degrees<br>Swivel: Left/Right: 45 degrees each<br>Rotation: Clockwise: 90 degrees  |  |  |
| Environm<br>Consider |                          | Operating:Temperature<br>Humidity5 to 35°C / 41 to 95°F<br>10 to 80% (No condensation)Storage:Temperature<br>Humidity-20 to 60°C / -4 to 140°F<br>5 to 85% (No condensation)  |  |  |
| Approval             | S                        | TCO Certified, CE, TÜV-GS, EAC  |  |  |


**NOTE** \* USB peripheral and audio equipment are not connected.

# SPECIFICATIONS : ProLite XU2792QSU


| Size Category                          |                  | 27"   |  |  |
|--|------------------|---|--|--|
| LCD<br>Panel                           | Panel technology | IPS (In-Plane-Switching)  |  |  |
|  | Size             | Diagonal: 27" (68.5cm)  |  |  |
|  | Pixel pitch      | 0.233mm H × 0.233mm V   |  |  |
|  | Brightness       | 350cd/m² (Typical)  |  |  |
|  | Contrast ratio   | 1000 : 1 (Typical), Adv. Contrast Function Available  |  |  |
|  | Viewable angle   | Right / Left: 89 degrees each, Up / Down: 89 degrees each (Typical)   |  |  |
|  | Response time    | 5ms (Gray to Gray)  |  |  |
| Display Colors                         |                  | 1.07 Billion  |  |  |
| Sync Frequency                         |                  | DVI: Horizontal: 30.0-89.0kHz, Vertical: 55-75Hz<br>HDMI: Horizontal: 30.0-89.0kHz, Vertical: 55-75Hz<br>DisplayPort(without FreeSync): Horizontal: 30.0-89.0kHz, Vertical: 50-75Hz<br>DisplayPort(with FreeSync): Horizontal: 30.0-115.0kHz, Vertical: 48-70Hz |  |  |
| Native Resolution                      |                  | 2560 × 1440, 3.7 MegaPixels   |  |  |
| Support max. resolution                |                  | DVI: 2560 × 1440 60Hz<br>HDMI: 2560 × 1440 60Hz<br>DisplayPort(without FreeSync): 2560 × 1440 70Hz<br>DisplayPort(with FreeSync): 2560 × 1440 70Hz  |  |  |
| Input Connector                        |                  | DVI-D, HDMI, DisplayPort  |  |  |
| Plug & Play                            |                  | VESA DDC2B <sup>™</sup>   |  |  |
| Input Video Signal                     |                  | DVI (Digital Visual Interface Standard Rev.1.0) compliance<br>HDMI, DisplayPort   |  |  |
| USB Standard                           |                  | USB3.0 (DC5V, 900mA)  |  |  |
| Number of USB Ports<br>Connector shape |                  | 1 Upstream : Series B<br>2 Downstream : Series A  |  |  |
| Input Audio Connector                  |                  | ø 3.5mm mini jack (Stereo)  |  |  |
| Input Audio Signal                     |                  | 1.0Vrms maximum   |  |  |
| Headphone Connector                    |                  | ø 3.5mm mini jack (Stereo)  |  |  |
| Speakers                               |                  | 2W × 2 (Stereo speakers)  |  |  |
| Maximum Screen Size                    |                  | 596.7mm W × 335.7mm H / 23.5" W × 13.2" H   |  |  |
| Power Source                           |                  | 100-240VAC, 50/60Hz, 1.5A   |  |  |
| Power Consumption*                     |                  | 33W typical, Standby mode: 0.5W maximum   |  |  |
| Dimensions / Net Weight                |                  | 611.0× 441.5 × 197.0mm / 24.1 × 17.4 × 7.8" (W×H×D)<br>5.0kg / 11.0lbs  |  |  |
| Tilt Angle                             |                  | Upward: 22 degrees Downward: 5 degrees  |  |  |
| Environmental<br>Considerations        |                  | Operating:Temperature<br>Humidity5 to 35°C / 41 to 95°F<br>10 to 80% (No condensation)Storage:Temperature<br>Humidity-20 to 60°C / -4 to 140°F<br>5 to 85% (No condensation)  |  |  |
| Approval                               | S                | TCO Certified, CE, TÜV-GS, EAC  |  |  |


**NOTE** \* USB peripheral and audio equipment are not connected.

# DIMENSIONS : ProLite XUB2792QSU



# DIMENSIONS : ProLite XU2792QSU





# COMPLIANT TIMING

| Video Mode  | Horizontal | Vertical  | Dot Clock  |   |
|-------------|------------|-----------|------------|---|
| VIGEO MODE  | Frequency  | Frequency | DOLOIOCK   |   |
| 640 × 480   | 31.469kHz  | 59.940Hz  | 25.175MHz  | ] |
| 800 × 600   | 37.879kHz  | 60.317Hz  | 40.000MHz  | ] |
| 1024 × 768  | 48.363kHz  | 60.004Hz  | 65.000MHz  | 1 |
| 1280 × 1024 | 63.981kHz  | 60.020Hz  | 108.000MHz | 1 |
| 1600 × 1200 | 75.000kHz  | 60.000Hz  | 162.000MHz | ] |
| 1680 × 1050 | 65.290kHz  | 60.000Hz  | 146.250MHz | ] |
| 1920 × 1080 | 66.590kHz  | 59.930Hz  | 138.500MHz | 1 |
| 2560 × 1440 | 88.787kHz  | 59.951Hz  | 241.500MHz | * |
| 2000 * 1440 | 104.045kHz | 69.923Hz  | 274.680MHz | * |

**NOTE** \*<sup>1</sup> DVI : Use the DVI-D dual-link signal cable.

\*<sup>2</sup> DisplayPort input only.