





















<p>Mi Smart Sensor Set User Manual</p>	<p>Thank you for choosing Mi Smart Sensor Set</p> <p>In the Mi Smart Sensor Set, a Control Hub works with a motion sensor, a window and door sensor, and a wireless switch to enable multiple functions such as, night lights on/off when the motion is detected, alert notifications and doorbell.</p> <p>It also works with other Mi smart devices in Mi Home app, allowing you to experience more exciting functions.</p>  <p>01</p>	<p>Quick Setup</p> <p>This set can interface and control other smart devices in Xiaomi Eco-system, using Mi Home app.</p> <p>1. Download Mi Home App</p> <p>Option 1: For Android users: download "Mi Home" from Google Play Store. For iOS users: download "Mi Home" from App Store.</p> <p>Option 2: Scan the QR code to download and install Mi Home app.</p>  <p>02</p>	<p>2. Connect to the network</p> <p>Power on the control hub and make sure that the phone is connected to a Wi-Fi network with a frequency of 2.4 GHz.</p>  <p>03</p>	<p>Product Overview</p> <p>1. Mi Control Hub Mi Control Hub is the control center for Mi Smart Sensor Set through which each sensor and switch can be interconnected and interacted.</p> <p>2. Mi Motion Sensor By using an infrared detector, Mi Motion Sensor detects movement of nearby people or pets and automatically turns on the night lights when you return home and turns them off when you leave home.</p>  <p>04</p>	<p>3. Mi Window and Door Sensor Mi Window and Door Sensor detects the state of doors and windows through the distance between the sensor unit and the magnet. It can achieve some function like the doorbell when the door opens interacted with Control Hub.</p>  <p>05</p>	<p>How to install</p> <p>Effective distance verification: press reset hole at the selected sensor installation location, the hub makes a sound to indicate that the location is suitable for hub connection.</p> <p>Mi Motion Sensor</p> <p>Option 1: Place directly in the desired position and keep it clean and dry.</p> <p>Option 2: Remove the protective film, and paste it directly in the desired position. The recommended installation height is 1.2 m to 2.1 m.</p> <p>*Note that the lens should be aligned with the detection area when installing, and placed or pasted as close as possible to the edge of the desk or cabinet.</p>  <p>06</p>	<p>Mi Window and Door Sensor</p> <p>1. Remove the protective film.</p> <p>2. During installation, try to align the marker line of the sensor unit and magnet.</p> <p>3. Paste it to the opening and closing position of doors and windows.</p> <p>Note: It is recommended to install the sensor unit in the opening and closing position of the fixed surface, the magnet on the movable surface, and make sure the installation gap is less than 12 mm when the doors and windows are closed.</p> <p>*Keep the surface clean and dry during pasting.</p> <p>*Avoid falling during installation, as the sensor is susceptible to damage.</p>  <p>07</p>	<p>Mi Wireless Switch</p> <p>Option 1: Place directly in the desired position and keep it clean and dry.</p> <p>Option 2: Remove the protective film, and paste it directly in the desired position.</p> <p>*Keep the surface clean and dry during pasting.</p> <p>*Do not install it on metal surfaces. Otherwise, it will affect the wireless communication range.</p>  <p>08</p>
---	---	---	---	---	--	--	--	---

<p>Please read this manual carefully before use, and keep it for future reference.</p> <p>Online Support : www.mi.com</p> <p>Manufactured for: Xiaomi Communications Co., Ltd.</p> <p>Manufactured by: Lumi United Technology Co., Ltd. (a Mi Ecosystem company)</p> <p>Address: F5, Jindafu office building, No.1 Tangping Rd., Luotian Ave., Toyuan SU-04L, Nanshan Dist., Shenzhen, China</p>	<p>Click the wireless switch to turn on/off night lights</p>  <p>Wireless switch Night lights</p> <p>Double click the wireless switch to turn on/off alert</p>  <p>Wireless switch Alert mode</p> <p>Door open reminder</p>  <p>Wireless switch Alert Hub notifications</p> <p>If you don't get hub open for more than 1 minute</p> <p>Add More Sub-devices</p> <p>Open Mi Home app, select Mi Control Hub, and follow prompts to add a sub-device until you hear a sound from hub indicating "Connected".</p> <p>* If not connected, move the sub-device closer to the hub and try again.</p> <p>09</p>	<p>Battery Replacement Instructions</p> <p>Mi Motion Sensor</p> <p>1. Open the motion sensor's battery cover by turning the cover in the counterclockwise direction.</p> <p>* If the motion sensor is attached to a wall, you can remove it from the wall by turning the sensor in the counterclockwise direction.</p>  <p>2. Remove the battery by hand or possibly use a non-metal tool.</p>  <p>3. Insert a CR1632 battery into the battery compartment.</p>  <p>4. Put the battery cover back in place.</p> <p>Mi Window and Door Sensor</p> <p>1. Open the battery cover using your hand or a tool.</p>  <p>2. Remove the battery by hand or possibly use a non-metal tool.</p>  <p>3. Insert a CR1632 battery into the battery compartment.</p>  <p>4. Put the battery cover back in place by turning it in the clockwise direction.</p> <p>Mi Wireless Switch</p> <p>1. Open the wireless switch's battery cover by gently pushing the battery cover latch and turning it in the counterclockwise direction.</p>  <p>2. Remove the battery by hand or possibly use a non-metal tool.</p>  <p>3. Insert a CR1632 battery into the battery compartment.</p>  <p>4. Put the battery cover back in place by turning it in the clockwise direction.</p> <p>10</p>	<p>CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. BEFORE USING BATTERIES, ACCORDING TO THE INSTRUCTIONS.</p> <p>RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.</p> <p>Symbol for "ENVIRONMENT PROTECTION" - Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local Authority or retailer for recycling advice.</p> <p>Symbol on the product or on its packing indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Complies with the European Union's "Restriction of Hazardous Substances Directive", which protects the environment by restricting specific hazardous materials and products.</p> <p>11</p>	<p>CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. BEFORE USING BATTERIES, ACCORDING TO THE INSTRUCTIONS.</p> <p>RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.</p> <p>Symbol for "ENVIRONMENT PROTECTION" - Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local Authority or retailer for recycling advice.</p> <p>Symbol on the product or on its packing indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Complies with the European Union's "Restriction of Hazardous Substances Directive", which protects the environment by restricting specific hazardous materials and products.</p> <p>12</p>	<p>CE SIMPLIFIED EU DECLARATION OF CONFORMITY</p> <p>Honery, LUMI UNITED TECHNOLOGY CO., LTD. declares that the radio equipment type is in compliance with RED 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.mi.com/en/service/support/declaration.html</p> <p>Specifications</p> <p>Mi Control Hub Model: D0HNG01LM Operating temperature: 0°C ~ 40°C Operating humidity: 0~95% RH, no condensation Input voltage: 100 ~ 240 V~, 50 Hz/60 Hz Wireless connectivity: Wi-Fi IEEE 802.11 b/g/n 2.4 GHz, ZigBee Frequency: 2400~2483.5 MHz</p> <p>Mi Motion Sensor Model: R10CG01LM Operating temperature: -10°C ~ 45°C Operating humidity: 0~95% RH, no condensation Detection range: ≤7 m Detection angle: ≤170°</p> <p>13</p>	<p>Battery model: CR1632 Wireless connectivity: ZigBee Frequency: 2400~2483.5 MHz</p> <p>Mi Window and Door Sensor Model: M10CG01LM Operating temperature: -10°C ~ 50°C Operating humidity: 0~95% RH, no condensation Battery model: CR1632 Wireless connectivity: ZigBee Frequency: 2400~2483.5 MHz</p> <p>Mi Wireless Switch Model: W10KG01LM Operating temperature: -10°C ~ 50°C Operating humidity: 0~95% RH, no condensation Battery model: CR1632 Wireless connectivity: ZigBee Frequency: 2400~2483.5 MHz</p> <p>14</p>	<p>15</p>	<p>16</p>
--	--	--	---	---	---	--	-----------	-----------